

**OPERATING,
MAINTENANCE
& PARTS
MANUAL**

**ELECTRIC
CHAIN HOIST**



LODESTAR XL

Before installing hoist, fill in the information below. Refer to the hoist identification plate.

Model No. _____

Serial No. _____

Purchase Date _____

Voltage _____

Rated Capacity _____

Rated capacities 2 through 7½ tons/
2000 through 7500 kg

Follow all instructions and warnings for inspecting, maintaining and operating this hoist.

The use of any hoist presents some risk of personal injury or property damage. That risk is greatly increased if proper instructions and warnings are not followed. Before using this hoist, each operator should become thoroughly familiar with all warnings, instructions and recommendations in this manual.

Retain this manual for future reference and use.

Forward this manual to operator. Failure to operate equipment as directed in manual may cause injury.

CM® XL HOIST PARTS AND SERVICES ARE AVAILABLE IN THE UNITED STATES AND IN CANADA

As a CM® XL Hoist user, you are assured of reliable repair and parts services through a network of Master Parts Depots and Service Centers that are strategically located in the United States and Canada. These facilities have been selected on the basis of their demonstrated ability to handle all parts and repair requirements promptly and efficiently.

Below is a list of the Master Parts Depots in the United States and Canada. To quickly obtain the name of the U.S. Service Center located nearest you, call (800) 888-0985. Fax: (716) 689-5644. In the following list, the Canadian Service Centers are indicated.

UNITED STATES MASTER PARTS DEPOT**CALIFORNIA**

OTTO SYSTEMS, INC.
12010 Bloomfield Ave.
Sante Fe Springs, CA 90670
562/462-1612 or 800/596-7392
Fax 562/462-1617

or
7656 Las Positas Road
Livemore, CA 94551
925/245-8800 or 800/508-6886
Fax 925/245-8804

GEORGIA

ACE INDUSTRIES, INC.
6295 McDonough Drive
Norcross, GA 30093
770/441-0898 or 800/733-2231
Fax 800/628-3648

ILLINOIS

JOHN SAKASH COMPANY, INC.
700 Walnut Street
Elmhurst, IL 60126
630/833-3940
Fax 630/833-9830

INDIANA

HORNER ELECTRIC COMPANY, INC.
1521 East Washington Street
Indianapolis, IN 46201
317/639-4261
Fax 317/639-4342

IOWA

VM HOIST & CRANE SERVICES
P.O. Box 440
450 Highway 151
Walford, IA 52351
319/846-6040
Fax 319/846-6045

KANSAS

INDEPENDENT ELECTRIC MACHINERY
4425 Oliver Street
Kansas City, KS 66106
913/362-1155 or 800/833-2610
Fax 913/904-3330

LOUISIANA

BEERMAN PRECISION, INC.
P.O. Box 6018
Metairie, LA 70009
504/207-6000
Fax 504/207-6044

MASSACHUSETTS

ABEL DISTRIBUTORS, INC.
50 Parker Street, Unit 2
Newburyport, MA 01950
978/463-0700
Fax 978/463-5200

NEW JERSEY

SHUPPER-BRICKLE EQUIPMENT CO.
P.O. Box 803
2394 Route 130, Suite C
Dayton, NJ 08810
732/438-3888
Fax 732/438-3889

NEW YORK

VOLLAND ELECTRIC EQUIPMENT CO.
75 Innsbruck Drive
Buffalo, NY 14227
716/656-9900
Fax 716/656-8899

NORTH CAROLINA

TEAM SESCO
P.O. Box 667489 28266
2225 Freedom Drive
Charlotte, NC 28208
704/372-4832 or 800/487-3726
Fax 704/358-1098

OHIO

MAZZELLA LIFTING TECHNOLOGIES
21000 Aerospace Parkway
Cleveland, OH 44142-1072
440/239-7000 or 800/362-4601
Fax 440/239-7010

PENNSYLVANIA

AMICK ASSOCIATES, INC.
11 Sycamore Street
P.O. Box 529
Carnegie, PA 15106-0529
412/429-1212 or 800/445-9456
Fax 412/429-0191

RAM MOTORS & CONTROLS, INC.
5460-B Pottsville Pike, Docka 8-11
P.O. Box 748
L Leesport, PA 19533
610/916-8000
Fax 610/916-7957

SOUTH CAROLINA

ENGINEERED SYSTEMS, INC.
1121 Duncan-Reidville Road
Duncan, SC 29334
864/879-7438 or 800/879-7438
Fax 864/879-6428

TEXAS

ABEL EQUIPMENT CO., INC.
3710 Cavalier Drive
Garland, TX 75042
972/272-7706
Fax 972/272-6955

HYDRAULIC EQUIPMENT SERVICES, INC.
1021 North San Jacinto Street
Houston, TX 77002
713/228-9601
Fax 713/228-0931

WISCONSIN

TRESTER HOIST & EQUIPMENT, INC.
W136 N4863 Campbell Drive
Suite #4
Menomonee Falls, WI 53051
262/790-0700 or 800/234-6098
Fax 262/790-1009

CANADIAN SERVICE CENTERS**ALBERTA**

BENNETT & EMMOTT, LTD.
18131 118th Avenue
Edmonton, Alberta T5S 1M8
403/454-9000
Fax 403/454-8990

**COLUMBUS McKINNON, LTD.
10311-174th Street
Edmonton, Alberta T5S 1H1
800/263-1997
Fax 403/486-6160

BRITISH COLUMBIA

FLECK BROTHERS, LTD.
4084 McConnel Court
Burnaby, British Columbia V5A 3N7

MANITOBA

KING'S ELECTRIC MOTORS, INC.
633 Tyne Avenue
Winnipeg, Manitoba R2L 1J5
204/663-5332
Fax 204/663-4059

NOVA SCOTIA

*W & A MOIR
95 Ilsley Ave.
Burnside Park, Nova Scotia B3B 1L5
902/468-7720
Fax 902/468-3777

ONTARIO

*R & W HOIST REPAIR, LTD.
790 Redwood Square
Units 5, 6, & 7
Oakville, Ontario L6L 6N3
905/825-5500
Fax 905/825-5315

*TORONTO ELECTRIC HOIST
SALES & SERVICE
9 CoDeco Court
North York, Ontario M3A 1A1
416/386-0820
Fax 416/386-0821

*MASLACK SUPPLY, LTD.
488 Falconbridge Road
Sudbury, Ontario P3A 4S4
705/566-1270
Fax 705/566-4208

*COLUMBUS McKINNON, LTD.
P.O. Box 1106
10 Brook Road, North
Cobourg, Ontario K9A 4W5
905/372-0153
Fax 905/372-3078

QUEBEC

*HERCULES SLING & CABLE
3800 TransCanada Highway
Pointe-Claire, Quebec H9R 1B1
514/428-5511
Fax 514/428-5555

*LEGER PALANS ET OUTILLAGES, INC.
7995-17th Ave.
Montreal, Quebec H1Z 3R2
514/376-3050
Fax 514/376-0657

*ARE ALSO MASTER PARTS DEPOTS

**MASTER PARTS DEPOT ONLY

SAFETY PRECAUTIONS

Each CM® Lodestar XL Electric Hoist is built in accordance with the specifications contained herein and at the time of manufacture complied with our interpretation of applicable sections of the *American Society of Mechanical Engineers Standard B30.16 "Overhead Hoists," the National Electrical Code (ANSI/NFPA 70) and the Occupational Safety and Health Act. Since OSHA states the National Electrical Code applies to all electric hoists, installers are required to provide current overload protection and grounding on the branch circuit section in keeping with the code. Check each installation for compliance with the application, operation and maintenance sections of these articles.

The safety laws for elevators, lifting of people and for dumbwaiters specify construction details that are not incorporated in Lodestar XL hoists. For such applications, refer to the requirements of applicable state and local codes, and the American National Safety Code for elevators, dumbwaiters, escalators and moving walks (ASME A17.1). Columbus McKinnon Corporation cannot be responsible for applications other than those for which CM equipment is intended.

* Copies of this Standard can be obtained from ASME Order Department, 22 Law Drive, Box 2300, Fairfield, NJ 07007-2300, U.S.A.

| | | |
|---|---|---|
|  | THIS SYMBOL POINTS OUT IMPORTANT SAFETY INSTRUCTIONS WHICH IF NOT FOLLOWED COULD ENDANGER THE PERSONAL SAFETY AND/OR PROPERTY OF YOURSELF AND OTHERS. READ AND FOLLOW ALL INSTRUCTIONS IN THIS MANUAL AND ANY PROVIDED WITH THE EQUIPMENT BEFORE ATTEMPTING TO OPERATE YOUR CM® LODESTAR XL HOIST. |  |
|---|---|---|

| |
|---|
|  WARNING |
| Usage of hoists that do not involve lifting of the load on the lower hook or using hoists in the inverted position without special precaution may cause an accident resulting in injury and/or property damage. |
| TO AVOID INJURY: |
| Consult Factory for information concerning using hoists in these applications. |

| |
|--|
|  WARNING |
| Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in <u>death</u> or <u>serious injury</u> . To avoid such a potentially hazardous situation, the operator shall: |

1. **Not** operate a damaged, malfunctioning or unusually performing hoist.
2. **Not** operate the hoist until you have thoroughly read and understood this Operating, Maintenance and Parts Manual.
3. **Not** operate a hoist which has been modified.
4. **Not** lift more than the rated load for the hoist.
5. **Not** use hoist with twisted, kinked, damaged or worn load chain.
6. **Not** use the hoist to lift, support, or transport people.
7. **Not** lift loads over people.
8. **Not** operate a hoist unless all persons are and remain clear of the supported load.
9. **Not** operate unless load is centered under hoist.
10. **Not** attempt to lengthen the load chain or repair damaged load chain.
11. Protect the hoist's load chain from weld splatter or other damaging contaminants.
12. **Not** operate hoist when it is restricted from forming a straight line from hook to hook in the direction of loading.
13. **Not** use load chain as a sling, or wrap load or chain around load.
14. **Not** apply the load to the tip of the hook or to the hook latch.
15. **Not** apply load unless load chain is properly seated in the chain wheel(s) or sproket(s).
16. **Not** apply load if bearing prevents equal loading on all load chains.
17. **Not** operate beyond the limits of the load chain travel.
18. **Not** leave load supported by the hoist unattended unless specific precautions have been taken.

19. **Not** allow the load chain or hook to be used as an electrical or welding ground.
20. **Not** allow the load chain or hook to be touched by a live welding electrode.
21. **Not** remove or obscure the warnings on the hoist.
22. **Not** operate a hoist on which the safety placards or decals are missing or illegible.
23. **Not** operate a hoist unless it has been securely attached to a suitable support.
24. **Not** operate a hoist unless load slings or other approved single attachments are properly sized and seated in the hook saddle.
25. Take up slack carefully - make sure load is balanced and load holding action is secure before continuing.
26. Shut down a hoist that malfunctions or performs unusually and report such malfunction.
27. Make sure hoist limit switches function properly.
28. Warn personnel of an approaching load.

| |
|--|
|  CAUTION |
| Improper operation of a hoist can create a potentially hazardous situation which, if not avoided, could result in <u>minor</u> or <u>moderate</u> injury. To avoid such a potentially hazardous situation, the operator shall: |

1. Maintain a firm footing or be otherwise secured when operating the hoist.
2. Check brake function by tensioning the hoist prior to each lift operation.
3. Use hook latches. Latches are to retain slings, chains, etc. under slack conditions only.
4. Make sure the hook latches are closed and not supporting any parts of the load.
5. Make sure the load is free to move and will clear all obstructions.
6. Avoid swinging the load or hook.
7. Make sure hook travel is in the same direction as shown on the controls.
8. Inspect the hoist regularly, replace damaged or worn parts, and keep appropriate records of maintenance.
9. Use the hoist manufacturer's recommended parts when repairing the unit.
10. Lubricate load chain per instructions in this manual.
11. **Not** use the hoist load limiting or warning device to measure load.
12. **Not** use limit switches as routine operating stops unless allowed by manufacturer. They are emergency devices only.
13. **Not** allow your attention to be diverted when operating hoist.
14. **Not** allow the hoist to be subjected to sharp contact with other hoists, structures, or objects through misuse.
15. **Not** adjust or repair the hoist unless qualified to perform such adjustments or repairs.

Hoist safety is up to you...

⚠ WARNING — DO NOT LIFT MORE THAN RATED LOAD.

1 CHOOSE THE RIGHT HOIST FOR THE JOB...

Choose a hoist with the capacity for the job. Know the capacities of your hoists and the weight of your loads. Then match them.

The application, the size and type of load, the attachments to be used and the period of use must also be taken into consideration in selecting the right hoist for the job.



Remember the hoist was designed to ease our burden and carelessness not only endangers the operator, but in many cases, a valuable load.

⚠ WARNING — DO NOT OPERATE DAMAGED OR MALFUNCTIONING HOIST
— DO NOT OPERATE WITH TWISTED, KINKED OR DAMAGED CHAIN.

2 INSPECT

All hoists should be visually inspected before use, in addition to regular, periodic maintenance inspections.

Inspect hoists for operations warning notices and legibility.

Deficiencies should be noted and brought to the attention of supervisors. Be sure defective hoists are tagged and taken out of service until repairs are made.



Under no circumstances should you operate a malfunctioning hoist.

Check chain for gouged, twisted, distorted links and foreign material. Do not operate hoists with twisted, kinked or damaged links.

Load chain should be properly lubricated.

Hooks that are bent, worn or whose openings are enlarged beyond normal throat opening should not be used. If latch does not engage throat opening of hook, hoist should be taken out of service.

Check for misphasing—hook travel should correspond to control direction.

Carefully check limit switches without a load. Care should be taken not to damage the hoist.



⚠ WARNING — DO NOT PULL AT AN ANGLE. BE SURE HOIST AND LOAD ARE IN A STRAIGHT LINE.
— DO NOT USE LOAD CHAIN AS A SLING.

3 USE HOIST PROPERLY



Be sure hoist is solidly held in the uppermost part of the support hook arc.



Be sure hoist and load are in a straight line. Do not pull at an angle.



Be sure load is hooked securely. Do not tip load the hook. Do not load hook latch. Hook latch is to prevent detachment of load under slack chain conditions only.



Do not use load chain as a sling. Such usage damages the chain and makes the limit switch setting ineffective.



Do not operate with hoist head resting against any object. Lift the load gently. Do not jerk it.


⚠ WARNING — DO NOT LIFT PEOPLE OR LOADS OVER PEOPLE.

4

Do not lift co-workers with a hoist.

Make sure everyone is clear of the load when you lift.

Do not remove or obscure operational warning notices.



5

CLEANING
Hoists should be kept clean and free of dust, dirt, moisture, etc., which will in any way affect the operation or safety of the equipment.

LUBRICATION
Chain should be properly lubricated.

AFTER REPAIRS
Carefully operate the hoist before returning it to full service.



VIOLETION OF ANY OF THE WARNINGS LISTED MAY RESULT IN SERIOUS PERSONAL INJURY TO THE OPERATOR OR NEARBY PERSONNEL BY RELEASED LOAD OR BROKEN HOIST COMPONENTS.

FOREWORD

This manual contains important information to help you properly install, operate and maintain your hoist for maximum performance, economy and safety.

Please study its contents thoroughly before putting your hoist into operation. By practicing correct operating procedures and by carrying out the recommended preventative maintenance suggestions, you will experience long, dependable and safe service. After you have completely familiarized yourself with the contents of this manual, we recommend that you carefully file it for future reference.

The information herein is directed to the proper use, care and maintenance of the hoist and does not comprise a handbook on the broad subject of rigging. Rigging can be defined as the process of lifting or moving heavy loads using hoist and other mechanical equipment. Skill acquired through specialized experience and study is essential to safe rigging operations. For rigging information, we recommend consulting a standard textbook on the subject.

TABLE OF CONTENTS

| ITEM | PAGE NO. | ITEM | PAGE NO. |
|--|----------|--|----------|
| MASTER PARTS DEPOTS AND SERVICE CENTERS | i | MAINTENANCE | |
| SAFETY PRECAUTIONS | ii | INSPECTIONS | 12 |
| HOIST SAFETY IS UP TO YOU | iii | FREQUENT INSPECTIONS | 12 |
| GENERAL INFORMATION | | PERIODIC INSPECTIONS | 12 |
| SPECIFICATIONS | 2 | HOOK INSPECTION | 12 |
| REPAIR/REPLACEMENT POLICY | 3 | LOAD CHAIN | 13 |
| ACCESSORIES | 3 | PROTECTOR | 13 |
| INSTALLATION | | LUBRICATION | |
| UNPACKING | 4 | HOIST | 15 |
| INSTALLING THE SUSPENSION | | TROLLEY | 15 |
| HOOK SUSPENSIONS | 4 | ADJUSTMENTS | |
| LUG SUSPENSIONS | 6 | HOIST BRAKE | 15 |
| MOUNTING TROLLEY ON HOIST | 6 | LIMIT SWITCHES | 16 |
| INSTALLING TROLLEY SUSPENDED | | TROLLEY BRAKE | 17 |
| HOIST ON BEAM | 7 | RECOMMENDED SPARE PARTS | 18 |
| INSTALLING BREATHER | 8 | PREVENTIVE MAINTENANCE | 18 |
| POWER SUPPLY SYSTEM | 8 | TROUBLE SHOOTING | |
| ELECTRICAL CONNECTIONS | | ALL HOISTS | 19 |
| SINGLE SPEED DUAL VOLTAGE | | TWO SPEED HOISTS | 22 |
| HOISTS (AND MOTOR DRIVEN TROLLEYS) | 9 | MOTOR DRIVEN TROLLEY | 23 |
| ALL HOISTS | 9 | ELECTRICAL DATA | 24, 25 |
| CHECKING FOR TWIST IN LOAD CHAIN | 10 | WIRING DIAGRAMS | 26, 28 |
| CHECKING FOR ADEQUATE VOLTAGE | 10 | DISASSEMBLY | 29 |
| CHECKING LIMIT SWITCH OPERATION | 10 | REASSEMBLY | 29 |
| CHAIN CONTAINER | 10 | REMOVAL AND REPLACEMENT OF LOAD CHAIN | 29 |
| CONTROL CORD | 10 | REEVING LOAD CHAIN | |
| OPERATING INSTRUCTIONS | | 3,4 AND 5 TON DOUBLE REEVED UNITS | 30 |
| GENERAL | 11 | 5,6 AND 7 1/2 TON TRIPLE REEVED UNITS | 31 |
| ALL HOISTS | 11 | CUTTING CHAINS | 31 |
| HOIST WITH PLAIN TROLLEY | 11 | TESTING | 32 |
| HOIST WITH GEARED TROLLEY | 11 | REPAIR PARTS | |
| HOIST WITH MOTOR DRIVEN TROLLEY | 11 | ORDERING INSTRUCTIONS | 32 |
| SAFETY PROCEDURES | 11 | EXPLODED VIEWS AND PARTS LISTS | 33-48 |

GENERAL INFORMATION

SPECIFICATIONS

The CM® LODESTAR XL Electric Chain Hoist is a highly versatile material handling device that can be used to lift loads that are within its rated load capacity. Single and Two speed units with rated loads up to 7½ tons (7500 kg.) are available. The hoist can be supplied with a single hook suspension up to 6 ton (6000 kg.) capacity or suspended from a plain, geared or motor driven trolley. The standard lift is 10 feet and longer lifts can be provided on a per order basis.

The standard features of the CM® LODESTAR XL Electric Chain Hoist include:

- Hardened, alloy steel, oblique lay liftwheel provides constant chain speed and reduces chain wear.
- Hoistaloy® load chain for long and dependable service.
- Lightweight cast aluminum frame and covers.
- Surface hardened, alloy steel, helical gears running in an oil bath provide smooth and quiet operation.
- Protector that prevents lifting an excessive overload.
- Single or two speed hoist duty motor equipped with thermal protection.
- Low voltage control circuit. 115 volt is standard. 24 or 48 volt control circuits are also available.
- Hardened, forged steel hooks equipped with latch.

- Oversize reversing and speed selecting contactors for long, trouble free service.
- Hoist duty, A.C. motor brake plus regenerative braking.
- Weatherproof, CM 2 or 4 direction control station.
- Shielded, lifetime lubricated ball bearings at all rotating points. Open bearings are used in gear case.
- Voltage conversion board on single speed, dual voltage units.
- Three stage gear reduction.
- Upper and lower screw type limit switches.



CM® LODESTAR XL Hoist with Motor Driven Trolley

**TABLE 1—SPECIFICATIONS
LODESTAR XL ELECTRIC CHAIN HOISTS**

| RATED LOAD | TONS Kg. | 2 2000 | | | 3 3000 | 4 & 5 4000 & 5000 | 5 5000 | 5 5000 | | 6 6000 | | | 7½ 7500 | |
|---|-------------|----------------------------|-----------|-----|-------------------------|----------------------|-------------|-------------|--------|-----------|--------|-----|------------|-----|
| | | *LIFTING SPEEDS AVAILABLE: | FPM | 18 | 24 | 30 | 9 | 12 | 15.2 | 6 | 8 | 6 | 8 | 10 |
| SINGLE SPEEDS | MPM | 5.5 | 7.3 | 9.1 | 2.7 | 3.6 | 4.6 | 1.8 | 2.4 | 1.8 | 2.4 | 3.0 | 1.8 | 3.0 |
| TWO SPEEDS | FPM | 6 / 18 | 8 / 24 | N/A | 3/9 | 4/12 | N/A | 2/6 | 2.7/8 | 2/6 | 2.7/8 | N/A | 2/6 | N/A |
| | MPM | 1.8 / 5.5 | 2.4 / 7.3 | N/A | .9/2.7 | 1.2 / 3.6 | N/A | .6/1.8 | .8/2.4 | .6/1.8 | .8/2.4 | N/A | .6/1.8 | N/A |
| MAXIMUM LIFT | FEET | 127 | 139 | 71 | 60 | 65 | 106 | 42 | 46 | 42 | 46 | 71 | 42 | 71 |
| | METERS | 39 | 42 | 22 | 19 | 21 | 32 | 13 | 14 | 13 | 14 | 22 | 13 | 22 |
| REEVING OF LOAD CHAIN | | SINGLE | | | DOUBLE | | | TRIPLE | | | | | | |
| MINIMUM HEADROOM | | | | | | | | | | | | | | |
| HOOK SUSPENDED—IN. (mm) | | 25 (635) | | | 35.31 (897) | | | 36.18 (919) | | | N/A | | | |
| TROLLEY SUSPENDED—IN. (mm) | | 28.69 (729) | | | 33 (841) | 33.38 (848) | 34.25 (870) | 34.25 (870) | | | | | | |
| RANGE OF TROLLEY ADJUSTABILITY "S" BEAMS | | 6 X 12.5' TO 15 X 42.9' | | | 8 X 18.4' TO 20 X 66.0' | | | | | | | | | |
| FLANGE WIDTH | IN. | 3.33 TO 5.50 | | | 4.00 TO 6.250 | | | | | | | | | |
| | mm | 84.5 TO 139.7 | | | 101.6 TO 158.8 | | | | | | | | | |
| STANDARD MOTOR DRIVEN TROLLEY TRAVEL SPEED—FPM (MPM) | | 65 (19.8) OR 100 (30.4) | | | 50 (15.2) | | | | | | | | | |
| **APPROX. NET WEIGHT—LBS. (Kg.) | | | | | | | | | | | | | | |
| HOOK SUSPENDED | | 368 (167) | | | 442 (200) | 442 (200) | | 474 (215) | | | | | | |
| WITH PLAIN TROLLEY | | 428 (194) | | | 497 (225) | 597 (271) | | 629 (285) | | | | | | |
| WITH GEARED TROLLEY | | 473 (215) | | | 512 (232) | 607 (275) | | 639 (290) | | | | | | |
| WITH MOTOR DRIVEN TROLLEY | | 483 (219) | | | 582 (264) | 632 (287) | | 664 (301) | | | | | | |

*Lifting speeds are based on 60 Hertz power supply. When operating on 50 Hertz, lifting speeds will be 5/6 of those listed.
**Weights are for single speed hoist with 10 ft. (3 M) lift. For two speed hoists, add 10 pounds (4.5 Kg.).

REPAIR/REPLACEMENT POLICY

All Lodestar XL Electric Chain Hoists are thoroughly inspected and performance tested prior to shipment. If any properly maintained hoist develops a performance problem due to a material or workmanship defect, as verified by factory, repair or replacement of the unit will be made to the original purchaser without charge. This repair/replacement policy applies only to LODESTAR XL Hoists installed, maintained and operated as outlined in this manual, and specifically excludes parts subject to normal wear, abuse, improper installation, improper or inadequate maintenance, hostile environmental effects and unauthorized repairs/modifications.

We reserve the right to change materials or design if, in our opinion, such changes will improve our product. Abuse, repair by an unauthorized person, or use of non-factory replacement parts voids the guarantee and could lead to dangerous operation. For full Terms of Sale, see Sales Order Acknowledgement. Also, refer to the back cover for Limitations of Warranties, Remedies and Damages, and Indemnification and Safe Operation.

ACCESSORIES

HOOK SUSPENSIONS

Hook suspensions are available for suspending 2 through 6 ton hoist from a trolley with a single load bar or for suspending the hoist from a fixed structure.



2 ton



3-6 ton

HOOK SUSPENSION

LUG SUSPENSIONS

Lug suspensions are required to suspend the LODESTAR XL Electric Hoist from plain, geared or motor driven trolleys described below. When the hoist is to be suspended from a plain, geared or motor driven trolley, the lug suspension is attached to the hoist prior to shipment.



LUG SUSPENSION

PLAIN TROLLEYS

These are manual push type trolleys designed for use with the LODESTAR XL Electric Hoist. The trolley is adjustable to operate on a range of American Standard 'S' beams and flat flanged beams. The plain trolley is mounted on hoist prior to shipment.



PLAIN TROLLEY

GEARED TROLLEYS

The geared trolley is similar to the plain trolley except it is moved by the means of a hand chain. The hand chain rotates a pinion that drives gears attached to trolley wheels and moves trolley along the beam. The geared trolley is mounted on the hoist prior to shipment.

MOTOR DRIVEN TROLLEYS

The motor driven trolley is similar to geared trolley except the hand chain wheel is replaced with a gear reducer and an electric motor. The motor is energized by a reversing contactor mounted inside the hoist and it is controlled by push buttons located in the pendant control station. A variety of single and two speed trolley travel speeds are available and the motor driven trolley is mounted on hoist prior to shipment.

INSTALLATION



MOTOR DRIVEN TROLLEY

CHAIN CONTAINER

This accessory is used to hold the slack chain and it is supplied complete with mounting hardware and instructions. The chain container is recommended for those applications where the slack chain will interfere with the load or drag on the floor as may be the case with double and triple reeved units. Chain containers are shipped separately and can be furnished for units already in use.



LATCHLOK® HOOKS

Latchlok hooks are available to replace the standard upper or lower latch type hooks (2-6 ton only). The unique design of the Latchlok hook assures that it will stay locked until the operator releases it by depressing the release button. It will not open accidentally—even if the load chain goes slack. Once opened, it can be shut with one hand or the weight of the load when it is lifted. Latchlok hooks can be supplied with the hoist or it can be provided in kit form for hoists already in service.




LATCHLOK® HOOK

UNPACKING


After opening the carton, carefully inspect the hoist, suspension, trolley and chain container for damage that may have occurred during shipment. If there is damage, refer to the packing slip envelope.

INSPECT FOR SHIPPING DAMAGE



| |
|---|
| ⚠ WARNING |
| Operating a unit with obvious external damage may cause load to drop and that may result in personal injury and/or property damage. |
| TO AVOID INJURY: |
| Carefully check unit for external damage prior to installation. |

Make sure that the power supply to which the hoist is to be connected is the same as that shown on the identification plate located on the bottom of the hoist. For single speed, dual voltage hoists, refer to instructions on page 8.




INSTALLING SUSPENSION

A. HOOK SUSPENSIONS

For hook suspended 2 through 6 ton units, the suspension is shipped separately and it must be attached to the hoist as follows:


1. **2 THROUGH 6 TON.** Supplied with the hook suspension is a counterweight that must be attached to the motor cover using the two long screws provided. Remove and discard corresponding motor cover screws. Place counterweight on motor cover and secure it using the two longer screws. Tighten these screws to a seating torque of 16 pound feet (22 NM).




Attach the "XL" label, from the kit, to counterweight in the recess provided for same.

2. 2 Ton Single Reeved Units. As shipped from the factory, the hook is rigid with the plane of the hook parallel to the long axis of the hoist. The hook can be changed to swivel type or the plane of the hook can be changed to perpendicular to the long axis of the hoist as follows:


- a. If a swivel type hook is required, use a 1/4 inch (6.4 mm) drift, and working through the hole in the side of the suspension adapter, drive the hook nut pin into the nut so that it is flush with the side of the nut. Discard the loose pin packed with the suspension.



- b. If it is necessary to position the hook so that the plane of the hook is perpendicular to the long axis of hoist, first convert to a swivel type hook as described above. Rotate the hook 90 degrees and slide the loose pin (packed with the suspension) through the hole in the side of the suspension adapter and engage the hole in the hook nut.




- c. After the hook is in the desired position, slide the suspension adapter into cavity on top of hoist and secure it using the suspension adapter screw from the kit. Tighten screw to a seating torque of 16 pound feet (22 NM).




NOTE: INSTALL BREATHER IN MAIN HOUSING AFTER HOOK SUSPENSION IS ASSEMBLED TO HOIST. SEE PAGE 8.

3. 3, 4 and 5 Ton Double Reeved and 5 and 6 Ton Triple Reeved Units. As shipped from the factory, the hook is rigid with the plane of the hook parallel to long axis of hoist. The hook can be changed to swivel type or the plane of the hook can be changed to perpendicular to the long axis of the hoist as follows:





- a. If a swivel type hook is required, remove and discard keeper plate screw and keeper plate. Then using a hammer, drive the hook nut pin into nut so that the end of the pin is flush with side of the nut.
- b. If it is necessary to position the hook so that the plane of the hook is perpendicular to long axis of hoist, first convert to a swivel type hook as described above but do not discard the keeper plate and screw. Turn hook 90 degrees and insert loose pin (packed with the suspension) into a hole in the hook nut. Loosely reassemble keeper plate to suspension adapter so that the hook is free to swivel approximately 45 degrees in either direction. The hook will be made rigid after suspension is attached to the hoist.



c. Slide the suspension adapter into cavity on top of hoist. Install dead end bolt and thread it by hand to engage the dead end block (3, 4 and 5 ton double reeved units) or idler sheave hanger (5 and 6 ton units). Then tighten dead end bolt to a seating torque of 120 pound feet (160NM).

2. **3, 4 And 5 Ton Double Reeved And 5, 6 And 7 1/2 Ton Triple Reeved Units.** Slide the suspension adapter into cavity on top of hoist. Install dead end bolt and thread it by hand to engage the dead end block (3, 4 and 5 ton double reeved units) or idler sheave hanger (5, 6 and 7 1/2 ton triple reeved units). Then tighten the dead end bolt to a seating torque of 120 pound feet (160 NM).




If the hook is to be perpendicular to long axis of hoist per step b above, rotate the hook to that position and firmly tighten the keeper plate screw while making sure the loose pin engages the slot in keeper plate.

NOTE: INSTALL BREATHER IN MAIN HOUSING AFTER HOOK SUSPENSION IS ASSEMBLED TO HOIST. SEE PAGE 8.

B. LUG SUSPENSIONS

The following instructions are provided to cover installing the lug suspension after the hoist has been reassembled following inspection and/or repair. On hoists shipped from factory, the lug suspension is installed prior to mounting the trolley.

1. **2 Ton Single Reeved Units.** Slide the suspension adapter into the cavity on top of hoist and secure it using the suspension adapter screw. Tighten the screw to a seating torque of 16 pound feet (22 NM).




| |
|--|
| ⚠ WARNING |
| Using other than factory supplied suspension adapter screw or dead end bolt to attach suspension adapter to hoist may cause the screw or bolt to break and allow the hoist and load to fall. |
| TO AVOID INJURY: |
| Use only the factory supplied suspension adapter screw or dead end bolt and tighten these to the seating torque specified above. |

MOUNTING TROLLEY ON HOIST

The following instructions are provided to cover mounting plain, geared and motor driven trolleys after the hoist has been reassembled following inspection and/or repair. On units shipped from factory, these trolleys are mounted on the hoists.

1. Measure actual width of the beam flange on which the trolley is to operate. To determine proper trolley side frame spacing to assure that adequate wheel clearance is provided, the distance between the beam flange and the inside face of the trackwheel flange (approximately 1/8 to 3/16 inch on straight runway beams, 3/16 to 1/4 inch on curved beams for 2 ton units. See Figure 2) and (1/4 inch for straight runway beams, 3/8 inch on curved beams for 3-7 1/2 ton units. See Figure 1).
2. Use Table 2 to determine proper spacing for 2 ton units. On 3-7 1/2 ton capacity units, proper spacing is obtained by varying the number of spacer washers (furnished with trolley) that are installed on the suspension pins.



- For 2 ton units, assemble a slotted nut to one end of each suspension bolt and secure it using a cotter pin. Spread legs of cotter pin to keep it in place. Using Table 2 as a reference for washer spacing, assemble side frames and bolts and washers together as shown below. Do not install remaining cotter pins at this time. These are to be installed after the trolley is mounted on the beam.

For 3-7½ ton units, temporarily assemble trolley to hoist using 3 or 4 washers at each end of suspension pins, between side plates and suspension lug. Tighten pin nuts for accurate check of spacing. Measure the distance between the inside faces of the trackwheel flanges and compare to the dimension required. Remove trolley side plates and add or remove an equal number of inside spacer washers as required to obtain proper distance between wheels. When spacing is correct, install all remaining spacer washers on the outside ends of each suspension pin and secure the pins with lockwashers and hex nut (See Note Below). The nuts should not be completely tightened until after hoist and trolley are mounted onto beam.

NOTE: It is very important that all spacer washers that come with the trolley be used. Install remaining spacer washers equally on outside ends of each suspension pin.

- On geared and motor driven trolleys, make sure the handwheel or motor is on loose end/chain container side of the hoist.




Figure 1.




Figure 2.

INSTALLING TROLLEY SUSPENDED HOIST ON BEAM

| | |
|---|----------------|
| | WARNING |
| Operating the trolley on a beam that has no rail stops may allow the trolley to fall off the end of the beam. | |
| TO AVOID INJURY: | |
| Install rail stops at each end of the beam on which the trolley is to operate. | |

Stops must be positioned to contact the trolley side frames and not exert impact force on the hoist.

Trolleys are mounted on the hoist prior to shipment and side frames are positioned for the nominal beam flange specified on the order. However, due to variations in beam flange widths, actual beam flange width should be measured to determine the exact distribution of the spacer washers. See Mounting Trolley On Hoist Section.

| | |
|---|----------------|
| | WARNING |
| If washer spacing recommendations are not followed, trolley may fall from beam. | |
| TO AVOID INJURY: | |
| Measure the actual beam flange on which the trolley is to operate and use Table 2 to determine the arrangement of the spacer washers for that flange width. | |

NOTE: USE OF OTHER THAN SUPPLIED SPACER WASHERS MAY CAUSE IMPROPER TRACKWHEEL SPACING.

Table 2. Trolley Spacer Washer Arrangement

| | Flange Width in.(mm) | 2 Ton | | | |
|---------------------------------|-------------------------|----------------|----|----|----|
| | | No. of Washers | | | |
| | | A | B | C | D |
| Standard Trolleys | 3-3/8 (85.7) | 13 | 0 | 0 | 13 |
| | 3-5/8 (92.0) | 11 | 2 | 2 | 11 |
| | 3-7/8 (98.4) | 10 | 3 | 4 | 9 |
| | 4 (101.6) | 9 | 4 | 4 | 9 |
| | 4-1/8 (104.7) | 8 | 5 | 5 | 8 |
| | 4-5/8 (117.4) | 5 | 8 | 8 | 5 |
| | 5 (127.0) | 3 | 10 | 10 | 3 |
| | 5-1/8 (130.1) | 3 | 10 | 11 | 2 |
| Special Trolleys | 5-1/4 (133.3) | 2 | 11 | 12 | 1 |
| | 5-1/2 (139.7) | 0 | 13 | 13 | 0 |
| | 5-5/8 (142.9) | 12 | 1 | 1 | 12 |
| | 6 (152.4) | 10 | 3 | 3 | 10 |
| | 6-1/4 (158.7) | 9 | 4 | 5 | 8 |
| | 6-3/8 (161.9) | 8 | 5 | 6 | 7 |
| | 7 (177.8) | 4 | 9 | 9 | 4 |
| | 7-1/8 (181.0) | 3 | 10 | 10 | 3 |
| | 7-1/4 (184.1) | 3 | 10 | 11 | 2 |
| | 7-3/8 (187.3) | 2 | 11 | 12 | 1 |
| 7-1/2 (190.5) | 1 | 12 | 12 | 1 | |
| 7-5/8 (193.7) | 0 | 13 | 13 | 0 | |
| * Minimum Beam Radius ft.(M) | | 4'-0"(1.22) | | | |

*Dimension applies to minimum S-beam and will vary with larger S-beams

Before installing geared or motor driven trolleys (2 ton only) on the beam, lubricate the trackwheel gears and pinion with Texaco Novatex #2 or equivalent heavy cup grease.

On open end beams, remove rail stops, lift hoist/trolley into position and slide the hoist/trolley assembly onto beam flange. Reinstall the rail stops.

On closed end beams, loosen the suspension bolt nuts on one side of trolley and slide one side frame out far enough to clear the beam flange. Lift hoist/trolley assembly up so that trackwheels are riding on beam flange. Draw side frames together by tightening the suspension bolt nuts snugly.

Be sure to install cotter pins through slotted nuts and hole in suspension bolts and spread legs of cotter pins to secure on 2 ton units. For 3-7 1/2 ton units, be sure lock-washers are positioned properly on the suspension pins and completely tightened.


On geared trolleys, the bottom of the hand chain loop is normally located two feet (0.6M) above the floor. If it is desired to change this, find the unwelded link and open it by spreading with a chisel or twist one end with a wrench while holding the other end in a vise or another wrench. Remove an even number of links (2,4,6, etc.) as necessary to shorten the chain or add an even number of links to lengthen the chain (when lengthening the chain, another open link will be required and this can be made from a welded link by cutting through weld with a hacksaw). Make certain that the chain is not twisted—then re-install and close open links.

NOTE: AFTER THE UNIT IS CONNECTED TO THE POWER SUPPLY SYSTEM (SEE BELOW), SUSPEND A CAPACITY LOAD FROM THE HOIST AND OPERATE THE TROLLEY OVER THE ENTIRE LENGTH OF THE RUNWAY OR MONORAIL SYSTEM TO BE SURE THAT THE ADJUSTMENTS AND OPERATION IS SATISFACTORY. ON SYSTEMS WITH CURVES, THE EDGES OF THE RAIL AT THE CURVED SECTIONS SHOULD BE KEPT LIGHTLY LUBRICATED WITH GREASE.

| |
|---|
| ⚠ WARNING |
| An excessively worn beam flange may fail and allow the trolley to fall from the beam. |
| TO AVOID INJURY: |
| Periodically inspect the beam flange for wear. Replace beam if flange is worn. |

INSTALLING BREATHER

After the hook suspension is assembled to the hoist or after the hoist and trolley are mounted on the beam, remove the upper plug from the main housing (652-110) and install the breather (from small envelope attached to the power cord). Failure to install the breather could damage oil seals and thus cause oil leaks.




POWER SUPPLY SYSTEM

To insure proper operation, to avoid damage to hoist and electrical system and to reduce the risk of electric shock or fire, the branch circuit supplying power to the hoist must:

1. Have ample capacity to prevent excess voltage drop during starting and operation (refer to "Checking for Adequate Voltage at Hoist" See Pg. 10). When determining the size of branch circuit components and conductors, special consideration should be given to the starting current-amps (approximately three times that shown on the hoist identification plate) and the length of the conductors. As a minimum, the system should be rated for 20 amps and it should have #12AWG, or larger, wiring.
2. Be in accordance with the National Electrical Code (ANSI/NFPA-70) and applicable National, State and Local Codes.
3. Effectively ground the hoist in accordance with National Electrical Code and other applicable codes. Proper grounding provides a path of least resistance for electric current to reduce the risk of electric shock. The power cord of the hoist includes a green wire for grounding the hoist to the external power supply system. If grounding is to be through the trolley trackwheels, each section of the runway must be grounded to the building ground system using metal to metal connections.
4. Include slow blow type fuses or inverse trip time circuit breakers to permit the hoist to start and accelerate load.
5. Include a disconnecting means capable of being locked in the "open" position.

| |
|---|
| ⚠ WARNING |
| Failure to properly ground the hoist presents the danger of electric shock. |
| TO AVOID INJURY: |
| Permanently ground the hoist as instructed in this manual. |



⚠ WARNING

Failure to provide a proper power supply system for the hoist may cause hoist damage and offers the potential for a fire.

TO AVOID INJURY:

Provide the hoist with a 20 amp, minimum, overcurrent protected power supply system per the National Electrical Code (ANSI/NFPA 70) and applicable local codes as instructed in this manual.


NOTE: IN THIS MANUAL, NOMINAL VOLTAGES ARE USED WHEN REFERRING TO POWER SUPPLY SYSTEMS. HOWEVER, WITH NO MODIFICATION, THE XL HOIST WILL OPERATE ON A RANGE OF VOLTAGES AS INDICATED BELOW:

| NOMINAL VOLTAGE | VOLTAGE RANGE | HERTZ |
|-----------------|---------------|-------|
| 230 | 208-240 | 60 |
| 460 | 440-480 | 60 |
| 220 | 200-240 | 50 |
| 380 | 365-395 | 50 |
| 415 | 400-430 | 50 |
| 575 | 550-575 | 60 |

**ELECTRICAL CONNECTIONS
SINGLE SPEED, DUAL VOLTAGE HOISTS (AND MOTOR DRIVEN TROLLEYS)**

Unless ordered on a special basis, single speed dual voltage (230/460-3-60, 220/380-3-50 and 220/415-3-50) hoists are factory wired to operate on 460-3-60 (or 380-3-50 or 415-3-50). However, a conversion terminal board is provided to easily and quickly change from 460 to 230 (or 380 to 220 or 415 to 220) volt operation. The conversion terminal board is located adjacent to the reversing contactor at motor end of hoist. If necessary, change voltage connections before connecting hoist to power supply system as follows:


1. Remove the motor cover (652-182). On units with hook suspension, it will be necessary to remove the counterweight (652-219) before removing motor cover.
2. Shift all eight wires from row of terminals marked "460" (or 380 or 415) to row of terminals marked "230" (or 220).



CONVERSION TERMINAL BOARD
MOVE ALL 8 WIRES TO CONVERT FROM 460 TO 230 (380 TO 220, 415 TO 220) VOLT OPERATION

3. Reassemble motor cover (and counterweight if so equipped) to hoist frame.
4. Mark the tag attached to power cord to indicate that the hoist has been converted to operate on 230 (or 220) volts and restamp hoist identification plate accordingly.

If the hoist is suspended from a single speed motor driven trolley, it will also be necessary to change the trolley motor connections. To do this, remove the cover from the terminal box mounted on the side of the trolley motor and reconnect the trolley motor wires attached to the terminal board as shown below:



TROLLEY VOLTAGE CONVERSION
(Connections shown are for 208-240 volt operation)

ALL HOISTS

After making sure that the hoist (and motor driven trolley) are wired to operate on the power supply system, you are now ready to connect hoist power cord to the power supply. Since these are three phase units, the hoist motor can rotate in either direction depending on how it is connected to the power supply. Therefore, direction of hook movement must be checked during the original installation and each time the hoist is moved to a new location.

Always disconnect the hoist from the power supply system or de-energize the power supply system and follow proper Lockout/Tagout procedures when working (connecting or disconnecting) with the hoist electrical connections. Serious damage will result if the hook is run to upper or

⚠ WARNING

FAILURE TO FOLLOW PROPER LOCKOUT/TAGOUT PROCEDURES MAY PRESENT THE DANGER OF ELECTRICAL SHOCK.

TO AVOID INJURY:

DISCONNECT POWER AND LOCKOUT/TAGOUT DISCONNECTING MEANS BEFORE REMOVING COVER OR SERVICING THIS EQUIPMENT.

lower limit of lift with hook moving in a direction opposite to that indicated by the control station. Connect hoist power cord to the power supply and check hook movement as follows:

1. Move the manual disconnect switch handle to the "OFF" position.
2. Connect the WHITE-PURPLE, RED AND BLACK wires of hoist power cord to load side of disconnect switch. Connect the GREEN wire of hoist power cord to power supply ground.

3. Move the manual disconnect switch handle to the "ON" position.
4. Depress the ↑ (up) control. If the hook moves in the up direction, the hoist is ready for operation. If the hook lowers, move the disconnect switch handle to the "OFF" position and interchange the BLACK and RED leads at the disconnect switch. Move the disconnect switch handle to the "ON" position and the hoist is now ready for operation.

| |
|--|
| WARNING |
| <p>Allowing the hook block to run into the bottom of the hoist when raising a load or allowing the chain to become taut between the loose end screw and the frame when lowering a load may break the chain and allow the load to drop.</p> |
| <p style="text-align: center;">TO AVOID INJURY:</p> <p>Do not allow the hook block to contact the bottom of the hoist or the loose end chain to become taut.</p> |

NOTE: DO NOT CHANGE INTERNAL WIRING OF HOIST OR CONTROL STATION TO REVERSE HOOK DIRECTION. THE HOIST AND CONTROL STATION WIRING WAS INSPECTED AND TESTED FOR PROPER OPERATION AT THE FACTORY. CHANGING THIS WIRING WILL CAUSE IMPROPER OPERATION AND SERIOUS DAMAGE.

Also, do not force the Protector to compensate for improperly adjusted limit switches or reverse voltage phasing.

CHECKING FOR TWIST IN LOAD CHAIN

3, 4 And 5 Ton Double Reeved Units

The best way to check for this condition is to run the lower hook, without a load, up to within about 2 feet (0.6M) of hoist. If the dead end of chain has been properly installed, a twist can occur only if the lower hook block has been capsized between the strands of chain. Reverse capsize to remove twist.

5,6 And 7 1/2 Ton Triple Reeved Units

On these models, the load chain is dead ended on top of the lower hook block. If chain has been properly installed, the only way a twist can occur is if the lower hook block has been capsized between the strands of chain. If this has occurred, two strands of chain will be wrapped around each other and to remove twist, reverse the capsize.

CHECKING FOR ADEQUATE VOLTAGE AT HOIST

The hoist must be supplied with adequate electrical power for proper operation and to reduce problems that may result from insufficient power (low voltage). These include:

- Noisy hoist operation due to brake and/or contactor chatter.
- Heating of the hoist motor and other internal components as well as heating of wires and connectors in the circuit feeding the hoist.
- Failure of the hoist to lift the load due to motor stalling.
- Blowing fuses or tripping circuit breakers.

For proper operation and to avoid these low voltage problems, voltage (measured at the end of the 2.5 foot (.9 M) power cord while lifting rated load) should be as follows:

| NOMINAL POWER SUPPLY | MINIMUM OPERATING VOLTAGE | * MIN. VOLTAGE AT INSTANT OF START |
|----------------------------|---------------------------------|--|
| 208-3-60 | 187 | 172 |
| 220-3-50 | 198 | 182 |
| 230-3-60 | 207 | 190 |
| 380-3-50 | 365 | 336 |
| 415-3-50 | 399 | 367 |
| 460-3-60 | 414 | 380 |

* The drop in voltage upon energizing the hoist should not be below the value listed.

Remember, operation with low voltage can void the Repair/Replacement policy. When in doubt about any of the electrical requirements for the power supply system, consult a qualified electrician.

CHECKING LIMIT SWITCH OPERATION

1. Press the ↑ (Up) control and raise the lower hook until the top of the hook block is about one foot (0.3M) below hoist.
2. Cautiously continue raising the hook until upper limit switch stops upward motion. At this point, the top of the hook block should be 3 inches (76 mm) below bottom of the hoist.
3. If adjustment is necessary, see page 16.
4. Press ↓ (Down) control and cautiously lower hook until lower limit switch stops the downward motion. From 10 to 12 chain links should be between the loose end link and the opening for the chain in bottom of hoist. If adjustment is necessary, see page 16.

| |
|--|
| WARNING |
| <p>Allowing the hook block to run into the bottom of hoist when raising a load or allowing the chain to become taut between the loose end screw and the frame when lowering a load may break the chain and allow the load to drop.</p> |
| <p style="text-align: center;">TO AVOID INJURY:</p> <p>Do not allow the hook block to contact the bottom of hoist or the loose end chain to become taut.</p> |

CHAIN CONTAINER

If a chain container is to be used, attach it to the hoist frame and place chain in container per instructions provided with the chain container kit. After the chain container is installed, follow the instructions on page 16 to reset upper limit switch so uppermost point of hook travel is just below the bottom of the chain container.

UNDER NO CIRCUMSTANCES SHOULD THE HOOK BLOCK OR LOAD BE PERMITTED TO COME IN CONTACT WITH THE CHAIN CONTAINER. IF CONTACT IS MADE, THE FUNCTION OF THE CHAIN CONTAINER CAN BE INTERFERED WITH, THE CONTAINER MAY BE DAMAGED AND IT COULD FALL OFF OF THE HOIST.

CONTROL CORD

Unless ordered on a special basis, the hoist is supplied with a control cord that will position the control station approximately 4 feet (1.2M) above the lower hook when it is at the lower limit of lift. If this places the control station too close to the floor, a "control cord alteration kit" (Key No. 627-474, Part Number 28642) can be obtained from factory for shortening the length of the control cord.


WARNING

Tying knots or loops to shorten the drop of the control station will make the strain relief ineffective and the internal conductors of the cord may break.

TO AVOID INJURY:

Shorten the control cord using the control cord alteration kit and the instructions provided with the kit.

OPERATING INSTRUCTIONS

GENERAL

1. The Protector is designed to allow the first reduction gear to slip on an excessive overload. An overload is indicated when the hoist will not raise the load. Also, some clutching noise may be heard if the hoist is loaded beyond rated capacity. Should this occur, immediately release the ↑(Up) control to stop operation of the hoist. At this point, the load should be reduced to the rated hoist capacity or the hoist should be replaced with one of the proper capacity. When the excessive load is removed, normal hoist operation is automatically restored.

CAUTION: THE PROTECTOR IS SUSCEPTIBLE TO OVER HEATING AND WEAR WHEN SLIPPED FOR EXTENDED PERIODS. UNDER NO CIRCUMSTANCE SHOULD THE PROTECTOR BE ALLOWED TO SLIP FOR MORE THAN A FEW SECONDS.

Due to the above, a hoist equipped with a Protector is not recommended for use in any application where there is a possibility of adding to an already suspended load to the point of overload. This includes *dumbwaiter installations, containers that are loaded in mid-air, etc.

*Refer to limitations on Page ii concerning dumbwaiter applications.

Also, if a XL Hoist with a Protector is used at unusual extremes of ambient temperatures, above 150°F (65°C) or below 15° F (-9°C) changes in lubricant properties may permit the hoist to raise larger loads than under normal operating conditions and presents possibility of damage or injury.

2. All hoists are equipped with an adjustable screw limit switch, which automatically stops the hook at any predetermined point when either hoisting or lowering.
3. The control station used on two speed hoists is similar to single speed unit, except that either of two definite speeds may be selected by the operator in both hoisting and lowering. Each control when partially depressed provides SLOW speed and when fully depressed gives FAST speed. Partial release of control returns hoist to slow speed, while complete release allows hoist to stop. Rated lifting speeds are shown on hoist identification plate. SLOW speed is intended as a means of carefully controlling or "spotting" the load, although the hoist may be operated solely at this speed if desired. It is not necessary to operate in the SLOW speed position as the hoist will pick up a capacity load at FAST speed from a standing start. In other words, it is not necessary to hesitate at the slow position when moving control from STOP and FAST position or vice versa.

4. If material being handled must be immersed in water, pickling baths, any liquid, dusty or loose solids, use a sling chain of ample length so that the hook is always above the surface. Bearings in the hook block are shielded only against ordinary atmospheric conditions.

5. Read operation section of American National Standard ASME B30.16.

ALL HOISTS

1. Before picking up a load, check to see that the hoist is directly overhead.
2. WHEN APPLYING A LOAD, IT SHOULD BE DIRECTLY UNDER HOIST OR TROLLEY. AVOID OFF-CENTER LOADING OF ANY KIND.
3. Take up a slack load chain carefully and start load easily to avoid shock and jerking of hoist load chain. If there is any evidence of overloading, immediately lower the load and remove the excess load.
4. Do not allow the load to swing or twist while hoisting.
5. Do not allow the load to bear against the hook latch.

HOIST WITH PLAIN TROLLEY

This unit should be moved by pushing on the suspended load or by pulling the empty hook. However, the unit can also be moved by pulling on the control station since an internal steel cable extends the length of the control cord and is anchored to the hoist and to the control station.

HOIST WITH GEARED TROLLEY

This unit should be moved by means of the pendant hand chain. Pull on the chain farthest from end toward which the unit is to travel.

HOIST WITH MOTOR DRIVEN TROLLEY

This unit should be moved by operating the controls marked < FORWARD and > REVERSE in control station. Anticipate the stopping point and allow trolley to coast to a smooth stop. Reversing or "plugging" to stop trolley causes overheating of motor and swaying of load.

SAFETY PROCEDURES

For safety precautions and a list of Do's and Do Not's for safe operation of hoists, refer to page ii.

1. When preparing to lift a load, be sure that attachments to hook are firmly seated in hook saddle. Avoid off center loading of any kind, especially loading on the point of hook.
2. When lifting, raise load only enough to clear the floor or support and check to be sure that the attachments to the hook and load are firmly seated. Continue lift only after you are assured the load is free of all obstructions.
3. Do not load hoist beyond the rated load shown on hoist identification plate and capacity labels. Overload can cause immediate failure of some load-carrying part or create a defect causing subsequent failure at less than rated load. When in doubt, use the next larger capacity of XL Hoist.

4. Do not use this or any other overhead materials handling equipment for lifting persons.
5. Stand clear of all loads and avoid moving a load over the heads of other personnel. Warn personnel of your intention to move a load in their area.
6. Do not leave load suspended in air unattended.
7. Permit only qualified personnel to operate unit.
8. Do not wrap the load chain around the load and hook onto itself as a choker chain.
Doing this will result in:
 - a. The loss of the swivel effect of the hook which could mean twisted chain and a jammed lift wheel.
 - b. The upper limit switch is by-passed and the load could hit the hoist.
 - c. The chain could be damaged at the hook.
9. On double and triple reeved hoists, check for twists in the load chain. A twist can occur if the lower hook block has been capsized between the strands of chain. Reverse the capsize to remove the twist.
10. Do not allow the load to bear against the hook latch. The latch is to help maintain the hook in position while the chain is slack before taking up slack chain.

WARNING

Allowing the load to bear against the hook latch and/or hook tip can result in loss of load.

TO AVOID INJURY:

Do not allow the load to bear against the hook latch and/or hook tip. Apply load to hook bowl or saddle

11. Take up a slack load chain carefully and start load easily to avoid shock and jerking of hoist load chain. If there is any evidence of overloading, immediately lower the load and remove the excess load.
12. Do not allow the load to swing or twist while hoisting.
13. Never operate the hoist when flammable materials or vapors are present. Electrical devices produce arcs or sparks that can cause a fire or explosion.
14. **STAY ALERT!** Watch what you are doing and use common sense. Do not use the hoist when you are tired, distracted or under the influence of drugs, alcohol or medication causing diminished control.

MAINTENANCE

INSPECTION

To maintain continuous and satisfactory operation, a regular inspection procedure must be initiated to replace worn or damaged parts before they become unsafe. Inspection intervals must be determined by the individual application and are based on the type of service to which the hoist will be subjected and degree of exposure to wear, deterioration or malfunction of the critical components.

The type of service to which the hoist is subjected can be classified as "Normal," "Heavy," or "Severe."

Normal Service: Involves operation with randomly distributed loads within rated load limit, or uniform loads less than 65 percent of rated load for not more than 25 percent of the time.

Heavy Service: Involves operating the hoist within rated load limit which exceeds normal service.

Severe Service: Normal or heavy service with abnormal operating conditions.

Two classes of inspection—**Frequent and Periodic**—must be performed.

FREQUENT INSPECTIONS: These inspections are visual examinations by the operator or other designated personnel. Records of such inspections are not required. The frequent inspections are to be performed monthly for normal service, weekly to monthly for heavy service, and daily to weekly for severe service, and they should include those items listed in Table 3.

PERIODIC INSPECTIONS: These inspections are visual inspections of external conditions by an appointed person. Records of periodic inspections are to be kept for continuing evaluation of the condition of the hoist. Periodic inspections are to be performed yearly for normal service, semi-annually for heavy service and quarterly for severe service, and they are to include those items listed in Table 4.


CAUTION: ANY DEFICIENCIES ARE TO BE CORRECTED BEFORE THE HOIST IS RETURNED TO SERVICE. ALSO, THE EXTERNAL CONDITIONS MAY SHOW THE NEED FOR DISASSEMBLY TO PERMIT A MORE DETAILED INSPECTION, WHICH, IN TURN, MAY REQUIRE THE USE OF NONDESTRUCTIVE TYPE TESTING.

HOOK INSPECTION

Hooks damaged from chemicals, deformations or cracks, or that have more than a 10° twist from the hook's unbent plane, excessive opening or seat wear must be replaced. Also, hooks that are opened and allow the latch to not engage the tip must be replaced. Any hook that is twisted or has excessive throat opening indicates abuse or overloading of the unit. Inspect other load sustaining parts for damage.

On latch type hooks, check to make sure that the latch is not damaged or bent and that it operates properly with sufficient spring pressure to keep the latch tightly against the tip of the hook and allow latch to spring back to tip when released. If latch does not operate properly, it should be replaced. See below to determine when the hook must be replaced.


LATCH TYPE HOOK
(Upper and Lower)
TO MEASURE OPENING,
DEPRESS LATCH AGAINST
HOOK BODY AS SHOWN.



* UPPER HOOK NOT AVAIL ABLE
FOR 7 1/2 TON

| CAPACITY (TONS) | Replace Hook When Opening Is Greater Than |
|--------------------|--|
| 2 | 1 1/2 IN. 38.1 mm |
| 3,4,5,6 AND 7 1/2 | 2 3/8 IN. 60.3 mm |

LATCHLOCK® TYPE HOOK
(UPPER AND LOWER)



| CAPACITY (TONS) | Replace Hook When Opening Or Seat are: | |
|--------------------|--|-----------------------|
| | "A" Max. | "B" Mn. |
| 2 | 2 1/2 IN. 63.5 mm | 1 1/8 IN. 28.5mm |
| 3,4,5, and 6 | 2 15/16 IN. 74.6 mm | 1 13/32 IN. 35.7mm |

Hook Inspection

LOAD CHAIN

Cleaning and Inspection

First clean load chain with a non-acid or non-caustic type solvent. Then slack the chain and make a link-by-link inspection for nicks, gouges, twisted links and excessive wear or stretching. Chain exhibiting wear should be checked throughout its entire length and replaced if worn beyond serviceable limits.

Checking For Load Chain Wear

Slack the portion of the chain that normally passes over the liftwheel. Examine the interlink area for the point of maximum wear (polishing). Measure and record the stock diameter at this point of the link. Then measure stock diameter in the same area on a link that does not pass over the liftwheel (use the link adjacent to the loose end link for this purpose). Compare these two measurements. If the stock diameter of the worn link is 0.010 inches (0.254mm), or greater, less than the stock diameter of the unworn link, the chain must be replaced.

Note that worn chain can be an indication of worn hoist components. For this reason, the hoist's chain guides, hook blocks and liftwheel should be examined for wear and replaced as necessary when replacing worn chain.

Also, these chains are specially heat treated and hardened and should never be repaired.

! WARNING

Using other than factory supplied load chain may cause the chain to jam in the hoist and/or allow the chain to break and the load to drop.

TO AVOID INJURY:

Due to size requirements and physical properties, use only Hoistaloy® load chain in the XL Hoists.

IMPORTANT:

DO NOT USE REPLACED CHAIN FOR OTHER PURPOSES SUCH AS LIFTING OR PULLING. LOAD CHAIN MAY BREAK SUDDENLY WITHOUT VISUAL DEFORMATION. FOR THIS REASON, CUT REPLACED CHAIN INTO SHORT LENGTHS TO PREVENT USE AFTER DISPOSAL.

PROTECTOR™

The Protector should operate for the normal life of hoist without service. The device has been calibrated at the factory for a specific capacity/gear ratio of XL Hoist. It is not adjustable and it is not interchangeable with other capacities/gear ratios.



XL Hoist with
Motor Driven
Trolley

Table 3. Minimum Frequent Inspections

| TYPE OF SERVICE | | | ITEM |
|-------------------|-----------------------------------|---------------------------------|--|
| Normal | Heavy | Severe | |
| ↑ Monthly ↓ | ↑ Weekly to Monthly ↓ | ↑ Daily to Weekly ↓ | a) Brake for evidence of slippage. b) Control functions for proper operation. c) Hooks for damage, cracks, twists, excessive throat opening, latch engagement and latch operation—see page 13. d) Load chain for adequate lubrication, as well as for signs of wear, damaged links or foreign matter—see page 15. e) Load chain for proper reeving and twists. |

Table 4. Minimum Periodic Inspections

| TYPE OF SERVICE | | | ITEM |
|------------------|--------------------------|--------------------------|--|
| Normal | Heavy | Severe | |
| ↑ Yearly ↓ | ↑ Every 6 Months ↓ | ↑ Every 3 Months ↓ | a) All items listed in Table 3 for frequent inspections. b) External evidence of loose screws, bolts or nuts. c) External evidence of worn, corroded, cracked or distorted hook block, gears, bearings, dead end block, dead end pin, dead end bolt and suspension components. d) External evidence of damage to hook retaining nut and pin. Also check the upper suspension adapter making sure it is fully seated in the hoist frame and that suspension adapter screw or dead end bolt is tight. e) External evidence of damage or excessive wear of the liftwheel and hook block sheave chain pockets. Widening and deepening of the pockets may cause the chain to lift-up in the pocket and result in binding between liftwheel and chain guide or between the sheave and hook block. Also, check the chain guide for wear or burring where the chain enters the hoist. Severely worn or damaged parts should be replaced. f) External evidence of excessive wear of brake parts, and brake adjustment—see page 15. g) External evidence of pitting or any deterioration of contactor contacts. Check the operation of the control station making sure the buttons operate freely and do not stick in either position. h) Inspect the electrical cords and cables and control station enclosure for damaged insulation. i) Inspect trolley trackwheels for external wear on tread and flange and for wear on internal bearing surfaces as evidenced by a looseness on the stud. Suspension components for damage, cracks, wear and operation. Also check suspension adapter screw or dead end bolt for proper tightness—(see pages 4, 5, and 6). j) Inspect the loose end link, loose end screw, dead end block on double reeved units and dead end plate on triple reeved units. Replace worn or distorted parts. k) Inspect the hook for excess free play or rotation. Replace worn parts as evidenced by excess free play or rotation. l) Inspect for oil leaks at the gasket on either side of intermediate plate. Tighten the screws used to attach the main housing and brake housing to intermediate plate. If leak persists, disassemble hoist (see page 27) and replace gaskets. m) Inspect inside of motor and brake housings for presence of oil. Oil in motor housing may be excess chain lubricant or a leaking seal. Wipe out oil and monitor. If leak persists, replace seal (652-122 or 652-132). Oil in brake housing is due to leaking seal. Replace seal (652-122 or 652-134). n) Check motor bolts for damage and replace if bent, cracked or damaged. o) Inspect all splines for signs of wear and deterioration. Replace splined parts if worn or damaged. |

LUBRICATION

| |
|---|
|  WARNING |
| The lubricants used in and recommended for the XL Hoist may contain hazardous materials that mandate specific handling and disposal procedures. |
| TO AVOID CONTACT AND CONTAMINATION: Handle and dispose of lubricants only as directed in applicable material safety data sheets and in accordance with applicable local, state and federal regulations. |

NOTE: TO ASSURE EXTRA LONG LIFE AND TOP PERFORMANCE, BE SURE TO LUBRICATE THE VARIOUS PARTS OF THE XL HOIST USING THE LUBRICANTS SPECIFIED BELOW. IF DESIRED, THESE LUBRICANTS MAY BE PURCHASED FROM THE FACTORY.

HOIST LUBRICATION

Gears. Check oil level in gear housing at least once a month, maintaining it at the bottom of oil level hole in main housing (652-110).

Drain housing every 2-3 years and refill with one gallon (3.86 liters) of gear oil Amoco 85W-140.

CAUTION: THE PROTECTOR IS TO OPERATE IN THE ABOVE MENTIONED OIL. DO NOT USE ANY OTHER TYPE OF LUBRICANT OR THE PROTECTOR WILL NOT OPERATE PROPERLY AND PARTS COULD BE DAMAGED.

The limit switch gears are of molded nylon and require no lubrication. Apply a light film of machine oil to the limit switch shaft threads at least once a year.

Chain Guides, Liftwheel & Sheave Wheels.

When the hoist is disassembled for inspection and/or repair, the chain guides, sheave wheels (on multi-reeved units) and liftwheel must be lubricated with Lubriplate Bar and Chain Oil 10-R (Fiske Bros. Refining Co.) prior to reassembly. Apply sufficient lubricant to obtain natural runoff and full coverage.

Load Chain. Keep chain lubricated with a small amount of lubricant. This will greatly increase the life of load chain. Do not allow the chain to run dry.

Keep it clean and lubricate at regular intervals with Lubriplate Bar and Chain Oil 10-R (Fiske Bros. Refining Co.) or equal lubricant. Normally, weekly lubrication and cleaning is satisfactory, but under hot and dirty conditions, it may be necessary to clean the chain at least once a day and lubricate it several times between cleanings. When lubricating the chain, apply sufficient lubricant to obtain natural runoff and full coverage.

| |
|---|
|  WARNING |
| Used motor oils contain known carcinogenic materials. |
| TO AVOID HEALTH PROBLEMS: Never use used motor oils as a chain lubricant. Only use Lubriplate Bar and Chain Oil 10-R as a lubricant for the load chain. |

Bearings. All bearings except the lower hook thrust bearings are pre-lubricated or are in an oil bath and need no lubrication. The lower hook thrust bearing should be lubricated at least once a month with heavy duty machine oil.

Miscellaneous. If unit is disassembled, splines inside coupling (652-103) should be coated with an EP type grease (such as Evans Products Co. Anti-Scoring Extreme Pressure Lub. No. 3) before reassembly.

TROLLEY LUBRICATION

Trackwheel bearings are pre-lubricated and require no lubrication.

Geared Trolley. Once a month lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.

Every six months lubricate handwheel shaft bearings in 3-in-1 machine oil.

Motor Driven Trolley. Once a month lubricate trackwheel gears with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.

For 2 ton trolleys, the motor bearings and reduction gears require no additional lubrication. However, if gears are disassembled, upon reassembly use Texaco Novatex No. 1 or an equivalent medium cup grease.


For 3-7 1/2 ton trolleys, the right angle worm gear reducer oil should be changed after the first 100 hours of operation, then after every 2500 hours of normal service. When replacing oil due to repairs or service, use Mobil SHC-626 or equal, for each oil change.

**ADJUSTMENTS
HOIST BRAKE**

The correct air gap between armature and field when brake is not energized, is 0.025 inch (.63 mm) and need not be adjusted until the gap reaches 0.045 inch (1.14 mm).

To adjust the brake, proceed as follows:

1. Disconnect hoist from power supply.
2. Remove brake end cover.
3. Before adjusting the gap, back off the brake nuts and examine friction linings and friction surfaces for wear, scoring or warpage (min.thk. .188). Also check shading coils to be sure they are in place and not broken. A missing or broken shading coil will cause the brake to be noisy when hoist is operated. Any of these symptoms indicate the need for replacement of parts.
4. Turn brake nuts clockwise gaging the air gap on each side and at both ends of the armature.
5. Replace cover, reconnect the power and check operation.




HOIST BRAKE
ADJUSTMENT

LIMIT SWITCHES

If limit switch operation has been checked as described on page 10 and is not operating correctly or is not automatically stopping the hook at a desired position, proceed as follows:

1. Disconnect hoist from power supply.
2. Remove brake end cover.
3. The positions of upper and lower limit switches are indicated on the fiber insulator.
4. Loosen the screws to permit guide plate to be moved out of engagement with the traveling nuts.
5. Reconnect hoist to power supply
6. Run hook to the desired upper or lower position, cautiously operating the hoist without load.
7. Disconnect hoist from power supply.
8. Moving one travel nut toward the other increases hook travel and away from the other decreases the travel. To adjust the upper limit, turn the nut nearest the switch indicated as "Upper Limit Switch". To adjust the lower limit, turn the nut nearest the switch marked "Lower Limit Switch". Turn the desired nut until it just breaks the limit switch contacts. An audible click will be heard as the switch opens. Continue to rotate the nut toward the switch an additional two full teeth.
9. Reposition the guide plate in the next slot and securely tighten screws.
10. Reconnect hoist to power supply and check the stopping point of the hook by first moving the hook about 10 inches (254 mm) away from the desired stopping point. Then move the hook towards the desired stopping point by jogging cautiously until the limit switch stops the motion. If the stopping point is not the desired position, repeat the above instructions.
11. Double check the adjustment by moving the hook about 2 feet (610 mm) from the desired stopping point and then run the hook into the limit with the control held in the fully depressed position.
12. Fine adjustment of the screw limits setting may be obtained by inverting the guide plate. The offset on the plate gives adjustments equivalent to 1/2 notch (see Table below). When inverting the plate, it may be necessary to use the notch adjacent to the one used in the preliminary setting.



LIMIT SWITCHES

- | | |
|--------------------------|----------------|
| 1. Limit switch sub-assy | 4. Guide Plate |
| 2. Limit switch shaft | 5. Screws |
| 3. Traveling nuts | |

HOOK TRAVEL PER NOTCH OF LIMIT SWITCH NUT

| RATED LOAD TONS (Kg.) | PARTS OF CHAIN (REEVING) | *LIFT SPEED FPM (MPM) | MAX. LIFT FT. (M) | HOOK TRAVEL PER NOTCH IN.(mm) |
|-----------------------|--------------------------|-----------------------|-------------------|-------------------------------|
| 2 (2000) | 1 | 18 (5.5) | 127 (39) | 1.10 (27.9) |
| 2 (2000) | | 24 (7.3) | 139 (42) | 1.27 (32.3) |
| 2 (2000) | | 30 (9.1) | 212 (65) | 0.63 (16.0) |
| 3 (3000) | 2 | 9 (2.7) | 60 (18) | 0.55 (14.0) |
| 3 (3000) | | 12 (3.6) | 65 (20) | 0.64 (16.1) |
| 3 (3000) | | 15.2 (4.6) | 106 (32) | 0.93 (23.6) |
| 4 (4000) | | 9 (2.7) | 60 (18) | 0.55 (14.0) |
| 4 (4000) | | 12 (3.6) | 65 (20) | 0.64 (16.1) |
| 4 (4000) | | 15.2 (4.6) | 106 (32) | 0.93 (23.6) |
| 5 (5000) | | 9 (2.7) | 60 (18) | 0.55 (14.0) |
| 5 (5000) | | 12 (3.6) | 65 (20) | 0.64 (16.1) |
| 5 (5000) | | 15.2 (4.6) | 106 (32) | 0.93 (23.6) |
| 5 (5000) | 3 | 6(1.8) | 42 (13) | 0.37 (9.3) |
| 5 (5000) | | 8(2.4) | 46 (14) | 0.42 (10.8) |
| 6 (6000) | | 6 (1.8) | 42 (13) | 0.37 (9.3) |
| 6 (6000) | | 8 (2.4) | 46 (14) | 0.42 (10.8) |
| 6 (6000) | | 10 (3.0) | 71 (22) | 0.63 (16.0) |
| 7½ (7500) | | 6 (1.8) | 42 (13) | 0.37 (9.3) |
| 7½ (7500) | | 10 (3.0) | 71 (22) | 0.63 (16.0) |

* At 60 Hertz. For 50 Hertz speeds are 5/6 of those listed. Fast speeds are listed for two speed units.

TROLLEY BRAKE (2 TON UNIT)


(Optional Accessory)

The stopping distance of the Motor Driven Trolley equipped with an electric brake can be increased or decreased by adjusting the brake pressure. To increase brake pressure, and thereby decrease stopping distance, move the brake spacer washers progressively from the nut side of the brake field plate to the spring side. To decrease the stopping distance, move the washers in an opposite manner. Both studs must have the same number of washers on the spring side of the brake field plate.

The correct air gap between armature and field, when the brake is not energized, is 0.025 inch (.63 mm) and need not be adjusted until the gap reaches 0.045 inch (1.14 mm).

To adjust the air gap or brake pressure, proceed as follows:

1. Disconnect hoist from power supply.
 2. Remove brake cover.
 3. Before adjusting air gap or brake pressure:
 - a. Back off the brake nuts and examine friction linings and friction surfaces for excessive wear, scoring or warpage.
 - b. Check shading coils to be sure they are in place and not broken. A missing or broken shading coil will cause the brake to be noisy when trolley is operated.
- Any of these symptoms indicate the need for replacement of parts.
4. If brake pressure is to be adjusted, move brake spacer washers to the desired side of the brake field plate to increase or decrease pressure as indicated above.
 5. After spacer washers are positioned, turn brake nuts clockwise gaging the air gap at both ends.
 6. Replace brake cover, reconnect the power and check operation. If the stopping distance of the trolley is not as desired, repeat the above.



TROLLEY BRAKE (3 THUR 7½ TON UNITS)

(Optional Accessory)

The brake can be ordered with the trolley or it is available in kit form for installation on a unit in the field. To order a brake kit for an existing unit, order brake kit Key No. 29 and indicate the serial number of the trolley on which it is to be installed and the voltage on which the trolley operates.




Figure 1. Motor Brake Adjustment

ADJUSTMENT

The motor brake should be checked periodically for wear of the friction discs and/or proper adjustment of the solenoid air gap. Refer to Figure 1. Normal lining wear will cause the solenoid lever (8) to move away from the solenoid frame (79) and thus increase the air gap and trolley stopping time.

When the air gap reaches approximately 11/16" the brake should be adjusted. To adjust the air gap of the brake, proceed as follows:

1. De-energize the power supply to trolley.
2. Remove both access covers to expose brake.
3. Depress the plunger (13) towards the solenoid frame until spring pressure is felt.
4. Hold the plunger firmly in the position and measure the air gap between the mating (ground) surfaces of the solenoid (79) and the solenoid plunger (29).
5. To adjust, turn both wear adjustment screws (10) equal amounts clockwise until the air gap measures 13/32".

Replacement of Friction Disc (Refer to Exploded View Drawing, Page 47)

1. De-energize the power supply to the trolley and remove the motor/brake assembly from the gear reducer. Remove housing (3) from the brake.
2. Remove the entire support plate assembly by unscrewing 3 screws (32). Remove the stationary disc (11) and worn friction disc (12). Install the new friction disc, making sure that the two stabilizing springs are at 90° in the recessed portion of the squared hole in the friction disc, with the prongs pointing into the brake. Place the stationary disc on the friction disc and re-assemble the entire support plate assembly engages the guide pins of the end plate.
3. Remove both access covers (5) from the housing (1) and slide the housing with its shaft assembly on to the mounting studs. Be sure the housing is assembled with access windows above the horizontal centerline. Rotate shaft to engage key into the hub keyway.
4. Re-assemble the motor/brake assembly to the gear reducer using the four nuts and lockwashers.
5. Adjust air gap per above instructions (ADJUSTMENTS).
6. Re-energize power supply and operate trolley a few times to make sure air gap is correct and then replace access covers (5).

**Replacement of Coil
(Refer to Figure 1 on page 17 and Exploded View Drawing on page 48).**

1. De-energize the power supply to the trolley and remove the motor/brake assembly from the gear reducer.
2. Remove housing (3) from the brake and disconnect the coil wires from the cord.
3. Insert screw driver between support plate (126, Fig.1) and the top of lever arm (17, Fig.1). Wedge these apart and remove bearing pin (26, Fig.1) and solenoid lever (8, Fig.1) with link (13, Fig.1) and plunger (29, Fig.1).
4. Remove plunger guide screw (84, Fig.1) and both plunger guides (82, Fig.1). Slide old coil sideways out of the frame (79, Fig.1). If coil is difficult to move, tap lightly with a soft hammer.
5. Install new coil in the same relative position as the old coil and replace the plunge guides (82, Fig.1) and screw (84 and 84W, Fig.1).
6. Re-assemble following Step 3 in reverse order.
7. Re-connect the coil leads to the brake coil. Slide housing and shaft assembly onto mounting studs, rotating shaft to engage key into hub keyway. Be sure the access covers are above the horizontal centerline.
8. Re-assemble motor/brake assembly to gear reducer using the four nuts and lockwashers.
9. Adjust air gap per above instructions (ADJUSTMENT).
10. Re-energize power supply and operate trolley a few times to make sure air gap is correct and then replace access covers.

RECOMMENDED SPARE PARTS

To insure continued service of the XL Hoist, the following is a list of parts that are recommended to be kept on hand at all times to replace parts that have worn or failed. Parts applicable to your unit should be stocked.

| Key No. | Part Name | Qty. for Each Hoist in Service |
|---------|--|--------------------------------|
| 652-120 | Limit Switch Assembly | 1 |
| 652-130 | Brake Coil | 1 |
| 652-131 | Brake Friction Disc | 2 |
| 652-135 | Transformer | 1 |
| 627-563 | Control Station Parts Kit (2 Direction Station) | 1 |
| 627-565 | Control Station Switch Kit (2 Direction Station) | 1 |
| 635-155 | Control Station Switch Kit (4 Direction Station) | 1 |
| 652-136 | Hoist Reversing Contactor | 1 |
| 652-137 | Speed Selecting Contactor (2 Speed Hoists Only) | 1 |
| 652-138 | Trolley Reversing Contactor | 1 |
| 652-236 | Trolley Speed Selector (2 Speed Trolley Only) | 1 |

Refer to page 32 for ordering instructions and the parts list for part numbers.

PREVENTIVE MAINTENANCE

In addition to the inspection procedure on page 12, a preventive maintenance program should be established to prolong the useful life of the hoist and maintain its reliability and continued safe use. The program should include the periodic and frequent inspections with particular attention being paid to the lubrication of the various components using the recommended lubricants (see page 15).

TROUBLE SHOOTING

| TROUBLE | PROBABLE CAUSE | CHECK AND REMEDY |
|---|--|--|
| ALL HOISTS | | |
| <p>1. Hook does not respond to the control station.</p> | <p>A) No voltage at hoist—mainline or branch circuit switch open; branch line fuse blown or circuit breaker tripped.</p> <p>B) Phase failure (single phasing)—open circuit, grounded or faulty connection in one line of supply system, hoist wiring, reversing contactor, motor leads or windings.</p> <p>C) Upper or lower limit switch has opened the motor circuit.</p> <p>D) Open control circuit—motor thermal switch open; shorted or open winding in transformer, reversing contactor coil or speed selecting contactor coil; loose connection or broken wire in circuit; mechanical binding in contactor; control station contacts not closing or opening.</p> <p>E) Wrong voltage or frequency.</p> <p>F) Low voltage.</p> <p>G) Brake not releasing—open or shorted coil winding; armature binding.</p> <p>H) Excessive load.</p> | <p>A) Close switch, replace fuse or reset breaker.</p> <p>B) Check for electrical continuity and repair or replace defective part.</p> <p>C) Press the “other” control and the hook should respond. Adjust limit switches as described on page 15.</p> <p>D) Check electrical continuity thru thermal switch. If it is open, allow motor to cool. Should this not correct the trouble, check electrical continuity of other parts and repair or replace defective part.</p> <p>E) Use the voltage and frequency indicated on hoist identification plate. For three phase dual voltage unit, make sure the connections at the conversion and trolley terminal boards are the proper voltage as described on page 8.</p> <p>F) Check for low voltage condition as described on page 10.</p> <p>G) Check electrical continuity and connections. Check that correct coil has been installed. The coil for dual voltage unit operates at 230 volts when the hoist is connected for either 230 volt or 460 volt operation. Check brake adjustment as described on page 15.</p> <p>H) Reduce loading to the capacity limit of hoist as indicated on the identification plate.</p> |

| TROUBLE | PROBABLE CAUSE | CHECK AND REMEDY |
|---|--|---|
| 2. Hook moves in the wrong direction. | A) Wiring connections reversed at either the control station or terminal board. | A) Check connections with the wiring diagram. |
| | B) Phase reversal. | B) Refer to installation instructions on page 9 (all hoists). |
| 3. Hook lowers but will not raise. | A) Excessive load. | A) See Item 1H. |
| | B) Open hoisting circuit—open or shorted winding in reversing contactor coil or speed selecting contactor coil; loose connection or broken wire in circuit; control station contacts not making; upper limit switch contacts open. | B) See Item 1D. Also check operation of limit switch as described on page 10. |
| | C) Phase failure. | C) See Item 1B. |
| 4. Hook raises but will not lower. | A) Open lowering circuit—open or shorted winding in reversing contactor coil or speed selecting contactor coil; loose connection or broken wire in circuit; control station contacts not making; lower limit switch contacts open. | A) Check electrical continuity and repair or replace defective part. Check operation of limit switch operation as described on page 10. |
| 5. Hook lowers when hoisting control is operated. | A) Phase failure. | A) See Item 1B. |
| 6. Hook does not stop promptly. | A) Brake slipping. | A) Check brake adjustment as described on page 15. |
| | B) Excessive load. | B) See Item 1H. |
| | C) Protector slipping. | C) If Protector is not functioning properly, it should be replaced. |
| 7. Hoist operates sluggishly. | A) Excessive load. | A) See Item 1H. |
| | B) Low voltage. | B) Check for low voltage condition as described on page 10. |
| | C) Phase failure or unbalanced current in phases. | C) See Item 1B. |
| | D) Brake dragging. | D) Check brake adjustment as described on page 15. |

| TROUBLE | PROBABLE CAUSE | CHECK AND REMEDY |
|---|--|---|
| 8. Motor overheats. | <p>A) Excessive Load.</p> <p>B) Low Voltage.</p> <p>C) Extreme external heating.</p> <p>D) Frequent starting or reversing.</p> <p>E) Phase failure or unbalanced current in the phase.</p> <p>F) Brake dragging.</p> | <p>A) See Item 1H.</p> <p>B) Check for low voltage condition as described on page 10.</p> <p>C) Above an ambient temperature of 104°F. (40°C.), the frequency of hoist operation must be limited to avoid overheating of motor. Special provisions should be made to ventilate the space of shield the hoist from radiation.</p> <p>D) Avoid excessive inching, jogging or plugging. This type of operation drastically shortens the motor and contactor life and causes excessive brake wear.</p> <p>E) See Item 1B.</p> <p>F) Check brake adjustment as described on page 15.</p> |
| 9. Hook fails to stop at either or both ends of travel. | <p>A) Limit switches not opening circuits.</p> <p>B) Shaft not rotating.</p> <p>C) Traveling nuts not moving along shaft—guide plate loose; shaft or nut threads damaged.</p> | <p>A) Check switch connections, electrical continuity and mechanical operation. Check the switch adjustment as described on page 10. Check for a pinched wire.</p> <p>B) Check for damaged gears.</p> <p>C) Tighten guide plate screws. Replace damaged part.</p> |
| 10. Hook stopping point varies. | <p>A) Limit switch not holding adjustment.</p> <p>B) Brake not holding.</p> | <p>A) See Item 9.</p> <p>B) Check the brake adjustment as described on page 15.</p> |

| TROUBLE | PROBABLE CAUSE | CHECK AND REMEDY |
|---|----------------------------------|--|
| TWO SPEED HOISTS | | |
| 11. Hoist will not operate at slow speed in either direction. | A) Open Circuit. | A) Open or shorted motor winding, loose or broken wire in circuit, speed selecting contactor stuck in opposite speed mode. Replace motor, repair wire and/or replace speed selecting contactor. |
| | B) Phase failure. | B) See Item 1B. |
| 12. Hoist will not operate at fast speed in either direction. | A) Open circuit. | A) See Item 11A. |
| | B) Open speed selection circuit. | B) Open or shorted winding in speed selecting contactor coil. Loose connection or broken wire in circuit. Mechanical binding in contactor. Control station contacts not making or opening. Replace speed selecting contactor; repair connection, replace contactor or control station. |
| | C) Phase failure. | C) See Item 1B. |
| 13. Hook will not raise at slow speed. | A) Excessive load. | A) See Item 1H. |
| | B) Phase failure. | B) See Item 1B. |
| | C) Open circuit. | C) See Item 11A. |
| | D) Brake not releasing. | D) See Item 1G. |
| 14. Hook will not lower at slow speed. | A) Phase failure. | A) See Item 1B. |
| | B) Open circuit. | B) See Item 11A. |
| | C) Brake not releasing. | C) See Item 1G. |
| 15. Hook will not raise at fast speed. | A) Excessive load. | A) See Item 1H. |
| | B) Phase failure. | B) See Item 1B. |
| | C) Brake not releasing. | C) See Item 1G. |
| 16. Hook will not lower at fast speed. | A) Phase reversal. | A) See Item 1B. |
| | B) Brake not releasing. | B) See Item 1G. |
| 17. Hook moves in proper direction at one speed—wrong direction at other speed. | A) Phase reversal. | A) Wiring reconnected improperly. Interchange two leads of motor winding that are out of phase at the speed selecting contactor. |

| TROUBLE | PROBABLE CAUSE | CHECK AND REMEDY |
|---|---|---|
| MOTOR DRIVEN TROLLEY | | |
| 18) Trolley does not operate in either direction. | A) No voltage at motor. B) Phase failure. C) Open control circuit. D) Low voltage. E) Wrong voltage or frequency. | A) Open circuit, grounded or faulty connection in hoist wiring. B) See Item 1B. C) See Item 1D. D) See Item 1F. E) See Item 1E. |
| 19) Trolley operates in one direction only. | A) Open control circuit. | A) See Item 1D. |
| 20) Trolley operates sluggishly. | A) Excessive load. B) Low voltage. C) Unbalanced current in the phases. D) Brake dragging. | A) See Item 1H. B) See Item 1F. C) See Item 1B. D) Check electrical continuity and connections. Check that the correct coil has been installed. The coil for dual voltage units operate on 230 volts when the trolley is connected for either 230 or 460 volt operation. Check brake adjustment as described on page 17. |
| 21) Trolley motor overheats. | | A) See Item 8. |

ELECTRICAL DATA

**TO DETECT OPEN AND SHORT CIRCUITS
IN ELECTRICAL COMPONENTS**

Open circuits in the coils of electrical components may be detected by isolating the coil and checking for continuity with an ohmmeter or with the unit in series with a light or bell circuit.

Shorted turns are indicated by a current draw substantially above normal (connect ammeter in series with suspected element and impose normal voltage) or D.C.

resistance substantially below normal. The current method is recommended for coils with very low D.C. resistance.

Motor current draw in the stator should be measured with the rotor in place and running. Brake, relay and contactor coil current should be measured with the core iron in operating position.

| COILS | VOLTAGE | CURRENT DRAW (AMPS) AT 60 HERTZ | *D.C. RESISTANCE (OHMS) |
|---------------------------------------|-----------------|---------------------------------|-------------------------|
| HOIST REVERSING CONTACTOR COILS | 115 | 0.09 | 88.4 |
| | 48 | 0.46 | 3.6 |
| | 24 | 0.49 | 3.7 |
| HOIST SPEED SELECTING CONTACTOR COILS | 115 | 0.11 | 86.8 |
| | 48 | 0.25 | 14.4 |
| | 24 | N/A | N/A |
| TROLLEY REVERSING CONTACTOR COILS | 115 | 0.17 | 117.3 |
| | 48 | 0.30 | 18.2 |
| | 24 | 1.00 | 4.7 |
| HOIST BRAKE COILS | **220-240 | 1.39 | 2.4 |
| | 380-480 | 0.86 | 9.3 |
| | 575 | 0.39 | 14.9 |
| TROLLEY BRAKE COILS | **220-240 | 0.27 | 22.8 |
| | 380-480 | 0.16 | 89.4 |
| | 575 | 0.09 | 143.3 |
| | **220-240 | 0.20 | -- |
| | 380-480 (2 Ton) | 0.08 | -- |
| | 575 | 0.06 | -- |
| TROLLEY SPEED SELECTOR | 115 | 0.09 | 200.00 |
| | 48 | 0.20 | 31.9 |
| | 24 | 0.47 | 8.6 |

| TRANSFORMERS (652-135) | | *D.C. RESISTANCE (OHMS)-LEADS | | | | | |
|-------------------------------|-----------|-------------------------------|-------|-------|-------|-----|-------|
| VOLTS | | 16-17 | 18-19 | 16-18 | 16-19 | R-R | B-B |
| PRIMARY | SECONDARY | | | | | | |
| 208-240/380-480 | 110-120 | 43.3 | 48.1 | -- | -- | 7.8 | -- |
| 208-240/380-480 | 24 | 41.2 | 46.1 | -- | -- | 0.4 | -- |
| 220/380/440 | 48 | 21.9 | -- | 58.4 | 71.9 | 1.4 | -- |
| 550/575 | 110-120 | -- | -- | -- | -- | 7.6 | 145.5 |

| HOIST MOTORS (652-162) | | CURRENT (AMPS) | | *D.C. RESISTANCE (OHMS)-LEADS | | |
|-------------------------------|---------------------|-----------------------|-----------|--------------------------------------|------|-------|
| VOLTS-PHASE -HERTZ | H.P. (KW) | STARTING | FULL LOAD | 1-2 | 1-2 | 11-12 |
| | | | | 1-3 | 1-3 | 11-13 |
| | | | | 2-3 | 2-3 | 12-13 |
| 230/460-3-60 | 3.5 (2.7) | 18.4/6.4 | 11.5/5.8 | 4.4 | - | - |
| 220/380-3-50 | 3.5 (2.7) | 13.6/6.4 | 11.9/5.9 | 4.4 | - | - |
| 220/415-3-50 | 3.5 (2.7) | 13.6/6.4 | 11.9/5.8 | 4.4 | - | - |
| 230/460-3-60 | 5.7 (4.3) | 23.2/8.0 | 14.5/7.3 | 2.8 | - | - |
| 220/380-3-50 | 5.7 (4.3) | 17.0/8.0 | 14.9/7.4 | 2.8 | - | - |
| 220/415-3-50 | 5.7 (4.3) | 17.0/8.0 | 14.9/7.3 | 2.8 | - | - |
| 230-3-60 | 1.2/3.5 (.9/2.7) | 49.2/40.8 | 12.3/10.2 | - | 3.0 | 1.9 |
| 220-3-50 | 1.2/3.5 (.9/2.7) | 36.4/26.2 | 13.0/11.4 | - | 3.0 | 1.9 |
| 460-3-60 | 1.2/3.5 (.9/2.7) | 25.6/20.4 | 6.4/5.1 | - | 10.8 | 6.3 |
| 380-3-50 | 1.2/3.5 (.9/2.7) | 16.8/14.3 | 6.7/5.7 | - | 10.8 | 6.3 |
| 415-3-50 | 1.2/3.5 (.9/2.7) | 16.8/14.3 | 6.7/5.7 | - | 10.8 | 6.3 |
| 575-3-60 | 3.5 (2.7) | 9.5 | 3.8 | 6.9 | - | - |
| 575-3-60 | 1.2/3.5 (.9/2.7) | 14.5/11.3 | 5.8/4.5 | - | 15.8 | 9.9 |

| TROLLEY MOTORS (670-407) | | | | *D.C. RESISTANCE (OHMS)-LEADS | | | |
|---------------------------------|------------------|------------------------------|--|--------------------------------------|-------|-------|---------|
| VOLTS (3 PHASE) | HP (KW) | RPM (SYN.) AT 60 HERTZ | FULL LOAD CURRENT (AMPS) AT 60 HERTZ | T1-T4 | T7-T8 | T1-T2 | T11-T12 |
| | | | | T2-T5 | T7-T9 | T1-T3 | T11-T13 |
| | | | | T3-T6 | T8-T9 | T2-T3 | T12-T13 |
| 208-240/380-480 | .5 (.38) | 1200 | 1.95/.98 | 15.9 | 31.2 | - | - |
| 208-240/380-480 | .5 (.38) | 600 | 3.75/1.88 | 14 | 28 | - | - |
| 550-575 | .5 (.38) | 1200 | 0.70 | - | - | 101.2 | - |
| 550-575 | .5 (.38) | 600 | 1.80 | - | - | 86.3 | - |
| 208-240 | .25/.50(.19/.38) | 600/1200 | 3.00/2.60 | - | - | 25.0 | 27.1 |
| 380-480 | .25/.50(.19/.38) | 600/1200 | 1.30/1.10 | - | - | 105.9 | 106.9 |
| 208-240 | .25/.50(.19/.38) | 900/1800 | 4.5/8.1 | -- | -- | 17.3 | 30.6 |
| 380-480 | .25/.50(.19/.38) | 900/1800 | .8/.7 | - | - | 67.3 | 123.4 |
| 550-575 | .25/.50(.19/.38) | 900/1800 | .6/.7 | - | - | 123.0 | 187.5 |


| TROLLEY MOTORS (BET-3001) | | | | D.C. RESISTANCE (OHMS)-LEADS | | |
|----------------------------------|--------------|-----------------------------|---------------------------------------|-------------------------------------|-------------------------------|-------------------------------|
| VOLTS (3 PHASE) | H.P. (KW) | RPM (SYN) AT 60 HERTZ | FULL CURRENT (AMPS) AT 60 HERTZ | 230 VOLT | 460 VOLT | 575 VOLT |
| | | | | CT1-CT2 CT2-CT3 CT1-CT3 | CT1-CT2 CT2-CT3 CT1-CT3 | CT1-CT2 CT2-CT3 CT1-CT3 |
| 208-240/380/480 | .25 (.19) | 1800 | 1.35/.65 | 19.7 | 78.9 | -- |
| 208-240/380-480 | .5 (.38) | 1800 | .37 | 10.3 | 41.2 | -- |
| 550-575 | .25 (.19) | 1800 | 2.0/1.0 | -- | -- | 132.3 |
| 550-575 | .5 (.38) | 1800 | .80 | -- | -- | 66.2 |

*Resistance values are nominal and may vary from component to component.


**On dual voltage units (230/460-3-60, 220/380-3-50 and 220/415-3-60), brake coil operates on 230 (220) volts.

TYPICAL WIRING DIAGRAMS


Wiring diagrams shown are representative. Consult wiring diagram in hoist or furnished with unit.




SINGLE SPEED - HOIST ONLY




2 TON - SINGLE SPEED HOIST WITH TROLLEY




TWO SPEED - HOIST ONLY



2 TON - TWO SPEED HOIST WITH TROLLEY



3-7½ TON - SINGLE SPEED HOIST WITH TROLLEY



**3-7½ TON
2 SPEED HOIST WITH SINGLE SPEED TROLLEY**

DISASSEMBLY

Refer to pages 30 through 40 for exploded view and parts list. The following are general guide lines for disassembling the XL Hoist. Prior to disassembly:

1. Operate the hoist in the "down" direction until the lower limit is reached. Remove the brake end cover (652-181) and disengage the limit switch guide plate from the traveling nuts (see page 15). Remove the chain container or remove the loose end screw (652-256) and washers (652-257 and 652-258).
2. Carefully run the chain out of the hoist. On 3 and 4 ton units, the chain will remain suspended from the dead end block (652-204).
3. Disconnect the hoist from the power supply system and Lockout/Tagout disconnecting means.

| |
|--|
|  WARNING |
| Working in or near exposed energized electrical equipment presents the danger of electrical shock. |
| TO AVOID INJURY: DISCONNECT POWER AND LOCKOUT/TAGOUT DISCONNECTING MEANS BEFORE REMOVING COVER OR SERVICING THIS HOIST. |

4. Drain the oil from the hoist.
5. Remove the hoist from its support (hook suspended units) or remove the hoist and trolley from the beam. Remove the trolley from the hoist.

These guide lines cover the disassembly of the major mechanical components; not covered is the removal of obvious items such as hardware and seals. While disassembling the hoist, care should be taken so as to not damage the seals. Seals should be inspected for nicks or damage that could cause oil leaks. Damaged seals should be replaced prior to reassembly.

1. Remove brake end cover (652-181).
2. Remove the brake assembly (652-161) and brake hub (652-142).
3. Remove the entire limit switch assembly and the limit switch worm (652-146).
4. Remove the motor end cover (652-182) and the complete motor (652-162). Coupling (652-103) should remain on motor shaft.
5. On the 2, 3 and 4 ton units, remove chain plate (652-178). On the 5 and 6 ton units, remove the idler wheel housing (652-211) with idler wheel and bearings.
6. *Remove the brake housing (652-108) and gasket (652-118).
7. Remove the drive shaft and pinion (652-112).
8. Remove the Protector (652-160).
9. *Remove the intermediate plate (652-109) from the main housing (652-110) and remove gasket (652-118).
10. Remove the limit switch gear (652-149) from the limit switch input shaft (652-104) and remove the shaft from the intermediate plate.
11. Remove the second gear (652-159) from third reduction pinion and shaft (652-106) and remove the third reduction pinion and shaft from the main housing (652-110).
12. Remove the liftwheel gear (652-105) from the lift wheel (652-111).
13. Remove the motor housing (652-107) from the main housing (652-110).

14. Remove the chain stripper (652-114) and chain guide (652-113).
15. On the 3, 4, and 5 ton (Double Reeved) units, remove the dead end block (652-204) and chain.
16. Remove the liftwheel (652-111) from the main housing.

*Slots are provided in intermediate plate (652-109) to aid in the removal of screws.


REASSEMBLY

The reassembly of the hoist is, basically, the reverse of the above disassembly sequence. However, during reassembly:

1. If new seals are installed, make sure the lip of the seal is on the oil side.
2. Apply a light coat of gear oil to lips of all seals and surfaces of shafts that pass thru the seals.
3. Carefully slide the shafts through the seals.
4. The frame screws used to attach the motor and gear housings to the main frame should be tightened to a seating torque of 21 pound feet (28 NM).
5. Lubricate, especially the splines, as specified on page 14.
6. Make sure that "this side out" embossed on the liftwheel gear is visible when the gear is assembled to the liftwheel.
7. Place the load chain (with welds down and towards liftwheel. See illustration on page 27) over the liftwheel before attaching the motor housing to the main frame. After assembly reeve chain per page 27.
8. Follow instructions starting on page 4 when re-installing the unit.
9. After installation, test the unit as indicated on page 29.

REMOVAL AND REPLACEMENT OF LOAD CHAIN

USE ONLY STAR (H) GRADE LOAD CHAIN AND FACTORY REPLACEMENT PARTS. USE OF OTHER CHAIN AND PARTS MAY BE DANGEROUS AND VOIDS FACTORY WARRANTY.



| |
|--|
|  WARNING |
| USE OF COMMERCIAL OR OTHER MANUFACTURERS' CHAIN AND PARTS TO REPAIR XL HOISTS MAY CAUSE LOAD LOSS. |
| TO AVOID INJURY: |
| Use only factory supplied replacement load chain and parts. Chain and parts may look alike, but factory chain and parts are made of specific material or processed to achieve specific properties. |

Hoist load chain can be removed and installed using one of the following methods. Method 1 is recommended if only the load chain is replaced. Method 2 is recommended when the entire hoist is disassembled for repair and /or inspection.

METHOD 1


1. Disconnect the hoist from the power supply system.
2. Remove the motor end cover (652-182). On units with book suspension, remove the counterweight (652-219) prior to removing the motor cover.
3. Disengage the limit switch guide plate from the traveling nuts (see page 15).
4. Remove the chain container or remove the loose end of the chain from the hoist frame.
5. Using the procedures described on page 28 for cutting load chain, cut a portion out of the last loose end link to form a coupling link. The portion removed should be centered on the weld and be 1/2 inch (13mm) long. Remove burrs from cut edges.
6. Using the coupling link, attach the new chain to the old chain. Carefully check the welds on the new chain and make sure they are positioned the same as the old chain. The new chain must enter the hoist so that the welds are down and towards the lift wheel. See illustration below. Failure to properly position the chain will cause the chain to jam between the liftwheel and chain guide.
7. Re-energize power supply and carefully operate hoist in the "down" direction until approximately 6 feet (2 M) of the new chain is hanging free on the dead end side.
8. ON SINGLE REEVED UNITS, remove the hook block from the old chain, remove the coupling link, discard the old chain and attach the hook block to the new chain. ON DOUBLE REEVED UNITS, the hoist must be removed from the trolley before reeving the replacement load chain. For hook suspended units, the hook must be positioned so that the dead end bolt can be removed. If necessary, rotate hook approximately 45 degrees following the instructions on page 5. Now remove the chain plate and allow it and the dead end block spacer (652-253) to slide down the chain. Working through the cavity in the bottom of the hoist, hold the dead end block while loosening the dead end bolt. Remove the dead end block and remove the dead end pin. Remove the coupling link, pull the old chain out of the hook block and discard the old chain. Reeve the new load chain as described below. After reeving, mount trolley on hoist or reposition hook, if necessary, per installation instructions starting on page 4. ON TRIPLE REEVED UNITS, remove the dead end plate from the top of the hook block. Remove the dead end pin and remove the old chain from the dead end plate. Remove the coupling link, pull the old chain out of the hook block and idler sheave housing. Reeve the new load chain as described below.
9. Remount the chain container or reattach the loose end of the new chain to the hoist.
10. Reset upper and lower limit switches per page 15.

METHOD 2

1. Completely disassemble the hoist as described on page 26.
2. Prior to reassembly, inspect the liftwheel, chain guides and stripper for wear. If these parts are worn or damaged, they could cause premature wear of the chain. Replace worn or damaged parts.
3. Place chain on liftwheel with welds down and towards liftwheel as shown below. Welds must engage the relief machined in the bottom of the liftwheel pockets. If the chain is not properly placed

on the liftwheel, it will not be possible to install the chain guide. After making sure the chain is correctly installed on the liftwheel, continue to assemble the hoist.

4. On single reeved units, remove the hook block from the old chain and attach it to the new chain. On double and triple reeved units, reeve the new chain as described below.





5. Install the unit following the installation instructions starting on page 4.
6. Remount the chain container or reattach the loose end of the new chain to the hoist frame.
7. Reset upper and lower limit switches per page 15.

| |
|--|
| ▲WARNING |
| Improper installation (reeving) of load chain can result in dropped load. |
| TO AVOID INJURY: Properly reeve load chain per the following instructions. |

REEVING LOAD CHAIN**3, 4 AND 5 TON DOUBLE REEVED UNITS**

The following instructions assume that the trolley has been removed from the hoist or the upper hook has been positioned to provide access to the dead end bolt and that there is 6 feet (2 m) of chain hanging free on the dead end side of the hoist. Based on these, reeve the load chain as follows:

1. Slide the suspension adapter into the hoist frame, if has moved out of position or if it was removed.
2. Install the dead end bolt.
3. Attach a soft wire to the end of the chain. Feed the wire around the hook block sheave. **MAKING SURE THERE ARE NO TWISTS**, pull the chain thru the hook block.
4. Feed the chain thru the square opening in the chain plate and then thru the dead end block spacer.
5. Attach the last link of chain to dead end block using the dead end pin.
6. **MAKING SURE THERE ARE NO TWISTS IN THE CHAIN**, slide the dead end block into the cavity in hoist frame. Turn the dead end bolt by hand to thread it into the dead end block. Then tighten dead end bolt to a seating torque of 120 pound feet (160 NM).
7. Slide the chain plate and spacer up the chain and attach the chain plate to the hoist frame.
8. Retrace the chain and make sure there are no twists. If there are twists, start over.



5, 6 AND 7 1/2 TON TRIPLE REEVED UNITS

The following instructions assume that the idler wheel housing assembly has been attached to the suspension adapter and hoist frame, there is 6 feet (2 M) of chain hanging free on the dead end side of the hoist and the hoist is suspended from the trolley or permanent support.


Based on these, reeve the load chain as follows:

1. Attach a soft wire to the end of the chain. Feed the wire around the hook block sheave. MAKING SURE THERE ARE NO TWISTS IN THE CHAIN, pull the chain thru the hook block.
2. Feed the soft wire into the outboard side of the idler wheel housing and around the idler wheel. MAKING SURE THERE ARE NO TWISTS IN THE CHAIN, pull the chain over the idler wheel.
3. Remove the wire from the end of the chain and route chain down to the hook block. MAKING SURE THERE ARE NO TWISTS IN THE CHAIN, insert the last link of the chain into the slot in the dead end plate. Secure the chain using the dead end pin and attach the dead end plate to top of hook block. Tighten the dead end plate screws to a seating torque of 120 pound feet (160 NM).
4. Retrace chain and make sure there are no twists. If there are twists, start over.

CUTTING CHAINS


Hoistaloy® load chain is hardened and it is difficult to cut. The following methods are recommended when cutting a length of new chain from stock or cutting off worn chain. Always wear eye protection when cutting chain.

1. Use a grinder and nick the link on both sides (see below), then secure the link in a vise and break off with a hammer.



Cutting Chain by Nicking

2. Use a 7 inch (177 mm) minimum diameter by 1/8 inch (3.1 mm) thick abrasive wheel (or type recommended by wheel supplier) that will clear adjacent links.
3. Use a bolt cutter (See below) similar to the H.K. Porter No. 0590MTC with special cutter jaws for cutting hardened chain. Jaws should be 1 inch (25.4 mm) long.



Cutting Chain with a Bolt Cutter

| |
|--|
|  WARNING |
| Cutting Chain Can Produce Flying Particles. |
| TO AVOID INJURY: |
| <ul style="list-style-type: none"> • Wear Eye Protection • Provide A Shield Over Chain To Prevent Flying Objects |

TESTING

Before using, all altered, repaired or used hoists that have not been operated for the previous 12 months shall be tested by the user for proper operation. First, test the unit without a load and then with a light load of 50 pounds (23 kg) times the number of load supporting parts of load chain to be sure that the hoist operates properly and that the brake holds the load when control is released. Next test with a load of *125% of rated capacity. In addition hoists in which load sustaining parts have been replaced should be tested with *125% of rated capacity by or under the direction of an appointed person and written report prepared for record purposes. After this test, check that the Protector functions. If the Protector permits lifting a load in excess of 180% of rated load, it should be replaced.

NOTE: For additional information on inspection and testing, refer to American National Standard ASME B30.16 "Overhead Hoists" obtainable from The American Society of Mechanical Engineers, 345 East 47th Street, New York, NY 10017 U.S.A.

*If the Protector prevents lifting of a load of 125% of rated capacity, reduce load to rated capacity.

REPAIR PARTS

ORDERING INSTRUCTIONS

The following information must accompany all correspondence and orders for replacement parts:

1. Hoist rated load from identification plate.
2. Serial number of the hoist stamped below identification plate.
3. Voltage, Phase, Hertz from identification plate.
4. Length of lift.
5. Key number part from parts list.
6. Number of parts required.
7. Part name from parts list.
8. Part number from the parts list.

If trolley replacement parts are ordered, also include the type and capacity of the trolley.

NOTE: WHEN ORDERING REPLACEMENT PARTS, IT IS RECOMMENDED THAT CONSIDERATION BE GIVEN TO THE NEED FOR ALSO ORDERING SUCH ITEMS AS GASKETS, FASTENERS, INSULATORS, SEALS, ETC. THESE ITEMS MAY BE DAMAGED OR LOST DURING DISASSEMBLY OR JUST UNFIT FOR FUTURE USE BECAUSE OF DETERIORATION FROM AGE OR SERVICE.

| |
|--|
|  WARNING |
| Using "commercial" or other manufacturer's parts to repair the XL Hoists may cause load loss. |
| TO AVOID INJURY: |
| Use only factory supplied replacement parts. Parts may look alike but factory original parts are made of specific materials or processed to achieve specific properties. |

XL Electric Chain Hoist Parts List

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|--|-------------------------|
| 652-100 | 2 | BRAKE HUB SNAP RING | 35764 |
| 652-101 | 1 | 2ND GEAR SNAP RING | 36763 |
| 652-102 | 1 | 2ND PINION SNAP RING | 45766 |
| 652-103 | 1 | MOTOR SHAFT COUPLING FOR: 2, 3, 4, 5 AND 6 TON 5 TON (15 FPM UNITS) AND 7 1/2 TON (TRIPLE REEVED) | 52018 52078 |
| 652-104 | 1 | LIMIT SWITCH INPUT SHAFT | 52019 |
| 652-105 | 1 | LIFTWHEEL GEAR FOR: 2, 3, 4, 5 AND 6 TON 5 TON (15 FPM) AND 7 1/2 TON (10 FPM) | 52021 52076 |
| 652-106 | 1 | 3RD REDUCTION PINION AND SHAFT FOR: 2, 3, 4, 5 AND 6 TON 5 TON (15 FPM UNITS) AND 7 1/2 TON (10 FPM) | 52026 52075 |
| 652-107 | 1 | MOTOR HOUSING ASSEMBLY (See note 1) | 52631 |
| 652-108 | 1 | BRAKE HOUSING ASSEMBLY (See note 2) | 52632 |
| 652-109 | 1 | INTERMEDIATE PLATE ASSEMBLY (See note 3) | 52633 |
| 652-110 | 1 | MAIN HOUSING ASSEMBLY (See note 4) | 52630 |
| 652-111 | 1 | LIFTWHEEL | 52033 |
| 652-112 | 1 | DRIVE SHAFT AND PINION FOR: 2, 3, 4, 5 AND 6 TON 5 TON (DOUBLE REEVED) AND 7 1/2 TON (TRIPLE REEVED) | 52036 52079 |
| 652-113 | 1 | CHAIN GUIDE | 52041 |
| 652-114 | 1 | CHAIN STRIPPER | 52055 |
| 652-115 | 1 | LIMIT SWITCH SHAFT ASSEMBLY | 36623 |
| 652-116 | 1 | MOUNTING BRACKET | 52704 |
| 652-117 | 1 | CONTACTOR MOUNTING PLATE | 52706 |
| 652-118 | 2 | MAIN HOUSING GASKET | 52709 |
| 652-119 | 1 | LIMIT SWITCH SPRING | 52742 |
| 652-120 | 1 | LIMIT SWITCH ASSEMBLY | 52609 |
| 652-121 | 1 | BREATHER | 70726 |
| 652-122 | 2 | DRIVE SHAFT SEAL | 80401 |
| 652-123 | 2 | DRIVE SHAFT BEARING | 80402 |
| 652-124 | 1 | 2ND REDUCTION PINION BEARING - INBOARD | 80403 |
| 652-125 | 1 | 2ND REDUCTION PINION BEARING - OUTBOARD | 88429 |
| 652-126 | 1 | 3RD REDUCTION PINION BEARING - OUTBOARD | 80408 |
| 652-127 | 3 | CHAIN GUIDE PIN | 80410 |
| 652-128 | 1 | LIFTWHEEL BEARING - MOTOR END | 80411 |
| 652-129 | 1 | LIFTWHEEL SEAL - GEAR END | 80412 |
| 652-130 | 1 | *BRAKE COIL: (See note 5) 208-240 VOLT 380-480 VOLT 550-575 VOLT | 68877 68878 68879 |
| 652-131 | 2 | BRAKE FRICTION DISC | 70652 |
| 652-132 | 1 | LIFTWHEEL SEAL - INBOARD | 80415 |
| 652-133 | 1 | LIFTWHEEL GEAR SNAP RING | 80416 |
| 652-134 | 1 | LIMIT SWITCH INPUT SHAFT SEAL | 80417 |
| 652-135 | 1 | TRANSFORMER : 208-240/380-480 VOLT PRIMARY, 115 VOLT SECONDARY 208-240/380-480 VOLT PRIMARY, 48 VOLT SECONDARY | 68810 70793 |
| CONT. | | | |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|---|-------------------------|
| 652-135 | 1 | 208-240/380-480 VOLT PRIMARY, 24 VOLT SECONDARY 550-575 VOLT PRIMARY, 115 VOLT SECONDARY | 68811 68786 |
| 652-136 | 1 | HOIST REVERSING CONTACTOR WITH : 115 VOLT COILS 48 VOLT COILS 24 VOLT COILS | 52749 52751 52750 |
| 652-137 | 1 | SPEED SELECTING CONTACTOR WITH : 115 VOLT COIL 48 VOLT COIL 24 VOLT COIL | 70805 70806 70781 |
| 652-138 | 1 | TROLLEY REVERSING CONTACTOR WITH : 115 VOLT COILS 48 VOLT COILS 24 VOLT COILS | 28835 28846 28837 |
| 652-139 | -- | LINE CONNECTOR-SPECIFY NO REQ'D. | 982158 |
| 652-140 | 4 | MOTOR BOLT | 80429 |
| 652-141 | 2 | LIMIT SWITCH INPUT SHAFT BEARING | 88437 |
| 652-142 | 1 | BRAKE HUB | 68367 |
| 652-143 | 1 | LIFTWHEEL BEARING - GEAR END | 80413 |
| 652-144 | 1 | 3RD REDUCTION PINION BEARING - INBOARD | 88500 |
| 652-145 | 15 | FRAME SCREW | 987289 |
| 652-146 | 1 | LIMIT SWITCH WORM | 35756 |
| 652-147 | 1 | LIMIT SWITCH WORM PIN | 983766 |
| 652-148 | 1 | LIMIT SWITCH GEAR PIN | 983768 |
| 652-149 | 1 | LIMIT SWITCH GEAR FOR : 6, 9, 10, 15.2, 18, 30, 2/6, 3/9 AND 6/18 FPM 8, 12, 24, 8/2.7, 4/12 AND 8/24 FPM | 52720 52713 |
| 652-150 | 2 | FRAME PLUG (1") | 989074 |
| 652-151 | 1 | GROUND SCREW | 982686 |
| 652-152 | 2 | LIMIT SWITCH SHAFT BEARING | 35751 |
| 652-153 | 2 | LIM. SW. SHAFT BEARING SCREW | 983643 |
| 652-154 | 1 | LIMIT SWITCH GUIDE PLATE | 28714 |
| 652-155 | 2 | LIMIT SWITCH GUIDE PLATE SCREW | 983614 |
| 652-156 | 2 | FRAME PLUG (3/4") | 989055 |
| 652-157 | 1 | POWER CORD | 51108 |
| 652-158 | 1 | POWER CORD CONNECTOR | 983979 |
| 652-159 | 1 | 2ND GEAR FOR : 6, 9, 10, 15.2, 18, 30, 2/6, 3/9 AND 6/18 FPM 8, 12, 24, 2.7/8, 4/12, AND 8/24 FPM | 52043 52024 |
| 652-160 | 1 | PROTECTOR ASSEMBLY FOR : CAPACITY SPEED (TONS) (FPM) | |
| | | 2 18 AND 6/18 | 52613 |
| | | 2 24 AND 8/24 | 52614 |
| | | 2 30 | 52626 |
| | | 3 9 AND 3/9 | 52628 |
| | | 3 12 AND 4/12 | 52613 |
| | | 3 15 AND 5/15 | 52665 |
| | | 4 9 AND 3/9 | 52613 |
| | | 4 12 AND 4/12 | 52614 |
| | | 4 15 | 52626 |
| | | 5 6 AND 2/6 | 52627 |
| | | 5 8 AND 2.7/8 | 52613 |
| | | 5 9 AND 9/3 | 52665 |
| | | 5 12 | 52626 |
| | | 5 15.2 | 52661 |
| CONT | | | |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|--|----------------|
| 652-160 | 1 | PROTECTOR ASSEMBLY FOR: Con't: | |
| | | 6 6 AND 2/6 | 52613 |
| | | 6 8 AND 2.7/8 | 52614 |
| | | 6 10 | 52626 |
| | | 7 1/2 6 AND 2/6 | 52665 |
| | | 7 1/2 10 | 52661 |
| 652-161 | 1 | ELECTRIC BRAKE COMPLETE: | |
| | | 208-240/380-480 VOLT, ONE SPEED | 52606 |
| | | 208-240 VOLT, TWO SPEED | 52606 |
| | | 380-480 VOLT, TWO SPEED | 52611 |
| | | 550-575 VOLT, SINGLE AND TWO SPEED | 52612 |
| | | FOR: 5 TON (DOUBLE REEVED) | 52660 |
| | | AND 7 1/2 TON (TRIPLE REEVED) | |
| | | 208-240/380-480 VOLT, SINGLE SPEED | |
| 652-162 | 1 | MOTOR (ROTOR WITH BEARINGS, STATOR AND END BELL) FOR : | |
| | | 208-240/380-480 VOLT, SINGLE SPEED | 52710 |
| | | 208-240 VOLT, TWO SPEED | 52711 |
| | | 380-480 VOLT, TWO SPEED | 52712 |
| | | 550-575 VOLT, SINGLE SPEED | 52730 |
| | | 550-575 VOLT, TWO SPEED | 52754 |
| | | FOR: 5 TON (DOUBLE REEVED) | 52812 |
| | | AND 7 1/2 TON (TRIPLE REEVED) | |
| | | 208-240/380-480 VOLT, SINGLE SPEED | |
| | | | |
| 652-163 | -- | LOAD CHAIN - SPECIFY LENGTH REQ'D BURNISHED IN OIL ZINC | 85885 85886 |
| 652-164 | 1 | WIRING HARNESS FOR : | |
| | | SINGLE SPEED | 51109 |
| | | TWO SPEED | 51110 |
| 652-165 | 2 | CONTACTOR MOUNTING PLATE SCREW | 983747 |
| 652-166 | 1 | CONVERSION T.B. BRACKET | 52705 |
| 652-167 | 2 | BRACKET ATTACHING SCREW | 982683 |
| 652-168 | 1 | CONVERSION TERMINAL BOARD | 28828 |
| 652-169 | 1 | CONVERSION T.B. INSULATOR | 27776 |
| 652-170 | 3 | CONVERSION T.B. SCREW | 987847 |
| 652-171 | 3 | CONVERSION T.B. SCREW L.W. | 987873 |
| 652-172 | - | JUMPERS | - |
| | | FOR SINGLE SPEED: 3-51111, 4-51112, AND 3-51113 JUMPERS REQ'D. | |
| | | FOR TWO SPEED: 4-51111, 6-51112, AND 2-51114 JUMPERS REQ'D. | |
| 652-173 | 3 | TRANSFORMER SCREW | 987859 |
| 652-174 | 3 | TRANSFORMER SCREW L.W. | 987873 |
| 652-175 | 1 | LOWER HOOK WITH LATCH --- | |
| | | LATCH TYPE : | |
| | | 2 TON | 35612 |
| | | 3, 4, 5, 6 AND 7 1/2 TON | 52651 |
| | | LOWER HOOK --- LATCHLOK TYPE : | |
| | | 2-TON | 36681 |
| | | 3, 4, 5 AND 6 TON | 52625 |
| | | 3-6 TON LOWER LATCHLOK KIT | 5264 |
| 652-176 | 1 | HALF LINK | 52017 |
| 652-177 | 2 | HOOK BLOCK : | |
| | | 2 TON | 52025 |
| | | 3 AND 4 TON | 52049 |
| | | 5, 6 AND 7 1/2 TON | 52069 |
| 652-178 | 1 | CHAIN PLATE : | |
| | | 2 TON | 52046C |
| | | 3 AND 4 TON | 52048C |
| 652-179 | - | HOOK BLOCK SCREW : | |
| | | 2 TON - 4 REQ'D. | 982369 |
| | | 3 AND 4 TON - 4 REQ'D. | 80423 |
| | | 5, 6 AND 7 1/2 TON - 2 REQ'D. | 80423 |
| 652-180 | 2 | CHAIN PLATE OR IDLER HOUSING SCREW | 987288 |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|---|-------------|
| 652-181 | 1 | BRAKE END COVER | 52028C |
| 652-182 | 1 | MOTOR END COVER | 52031C |
| 652-183 | 1 | IDENTIFICATION PLATE: | |
| | | LODESTAR XL | 70728 |
| 652-184 | 4 | BRAKE END COVER SCREW | 80409 |
| 652-185 | 4 | I.D. PLATE DRIVE SCREW | 988271 |
| 652-186 | 2 | WARNING LABEL, ELECTRICAL | 24842 |
| 652-187 | 1 | LIFTWHEEL GEAR BEARING | 80414 |
| 652-188 | 1 | 2ND REDUCTION PINION FOR : | |
| | | 6, 9, 10, 15.2, 18, 30, 2/6, 3/9 AND 6/18 FPM | 52044 |
| | | 8, 12, 24, 2.7/8, 4/12 AND 8/24 FPM | 52023 |
| 652-189 | 1 | CAPACITY LABEL FOR : | |
| | | 2 TON | 52714 |
| | | 3 TON | 52724 |
| | | 4 TON | 52716 |
| | | 5 TON | 52726 |
| | | 6 TON | 52728 |
| | | 7 1/2 TON | 52757 |
| 652-190 | 1 | WARNING LABEL FOR : | |
| | | 2 TON | 52715 |
| | | 3 TON | 52725 |
| | | 4 TON | 52717 |
| | | 5 TON | 52727 |
| | | 6 TON | 52729 |
| | | 7 1/2 TON | 52785 |
| 652-191 | 1 | COIL RETAINER STRAP | 35704 |
| 652-192 | 1 | BRAKE BASE PLATE | 52607 |
| 652-193 | 1 | BRAKE FIELD PLATE | 59634 |
| 652-194 | 3 | BRAKE SPRING FOR: | |
| | | 2, 3, 4, 5 AND 6 TON | 68818 |
| | | 5 TON (DOUBLE REEVED) AND 7 1/2 TON (TRIPLE REEVED) | 52811 |
| 652-195 | 1 | BRAKE INTERMEDIATE PLATE | 68820 |
| 652-196 | 1 | BRAKE ARMATURE | 70657 |
| 652-197 | 3 | BRAKE NUT | 982448 |
| 652-198 | 4 | MOTOR COVER SCREW | 80409 |
| 652-199 | 2 | SPEED SELECTOR SCREW | 982706 |
| 652-200 | 1 | HOOK NUT OR COLLAR FOR : | |
| | | 2 TON | 35369 |
| | | 3, 4, 5, 6 AND 7 1/2 TON | 52047 |
| 652-201 | 1 | HOOK NUT OR COLLAR PIN FOR : | |
| | | 2 TON | 45946 |
| | | 3, 4, 5, 6 AND 7 1/2 TON | 80418 |
| 652-202 | 1 | LOWER HOOK THRUST BEARING FOR : | |
| | | 2 TON | 88505 |
| | | 3, 4, 5, 6 AND 7 1/2 TON | 80421 |
| 652-203 | 1 | SHEAVE WHEEL | 52050 |
| 652-204 | 1 | DEAD END BLOCK | 52051 |
| 652-205 | 1 | DEAD END PIN | 52057 |
| 652-206 | 2 | SHEAVE WHEEL BEARING | 80422 |
| 652-207 | 1 | DEAD END BOLT | 80424 |
| | | 3, 4, 5, 6 AND 7 1/2 TON | |
| 652-208 | 2 | HOOK BLOCK CAPACITY LABEL FOR : | |
| | | 3 TON | 52738 |
| | | 4 TON | 52739 |
| | | 5 TON | 52740 |
| | | 6 TON | 52741 |
| | | 7 1/2 TON | 52786 |
| 652-209 | 4 | CAPACITY LABEL DRIVE SCREW | 988271 |
| 652-210 | 1 | DEAD END PLATE | 52068 |
| 652-211 | 1 | IDLER WHEEL HOUSING | 52053C |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|---|-------------|
| 652-212 | 1 | IDLER WHEEL | 52054 |
| 652-213 | 1 | ANCHOR PIN | 52058 |
| 652-214 | 2 | IDLER WHEEL BEARING | 80425 |
| 652-215 | 6 | DEAD END PLATE SCREW | 52074 |
| 652-216 | 1 | LATCH KIT FOR: 2 TON | 45663 |
| | | 3, 4, 5, 6 AND 7½ TON | 52701 |
| 652-217 | 1 | SUSPENSION ADAPTER FOR : | |
| | | 2 TON | 52022 |
| | | 3, 4, 5 AND 6 TON | 52035 |
| 652-218 | 1 | UPPER HOOK NUT FOR : | |
| | | 2 TON | 52045 |
| | | 3, 4, 5 AND 6 TON | 52047 |
| 652-219 | 1 | COUNTERWEIGHT | 52061 |
| 652-220 | 1 | UPPER HOOK, LATCH TYPE, FOR : | |
| | | 2 TON | 52608 |
| | | 3, 4, 5 AND 6 TON | 52651 |
| | | UPPER HOOK, LATCHLOK TYPE FOR : | |
| | | 2 TON | 52624 |
| | | 3, 4, 5 AND 6 TON | 52625 |
| 652-221 | 1 | HOOK NUT PIN | 80418 |
| 652-222 | 1 | ANTI-ROTATION PIN FOR : | |
| | | 2 TON | 80419 |
| | | 3, 4, 5 AND 6 TON | 80420 |
| 652-223 | 2 | COUNTERWEIGHT SCREW | 80428 |
| 652-224 | 1 | SUSPENSION SCREW (2 TON ONLY) | 987208 |
| 652-225 | 1 | ANTI-ROTATION PLATE | 52708 |
| 652-226 | 1 | ANTI-ROTATION PLATE SCREW | 982371 |
| 652-227 | 1 | UPPER HOOK SUSPENSION, LATCH TYPE COMPLETE (SEE NOTE 6) : | |
| | | 2 TON | 5254 |
| | | 3, 4, 5 AND 6 TON | 5255 |
| 652-228 | 2 | LIMIT SWITCH BRACKET SCREW | 982708 |
| 652-229 | 2 | LIMIT SWITCH BRACKET SCREW L.W. | 982226 |
| 652-230 | 1 | LIMIT SWITCH BRACKET | 35032 |
| 652-231 | 1 | LIM. SW. ASSEMBLY ATTACH. SCREW | 983614 |
| 652-232 | 1 | DRAIN PLUG | 989050 |
| 652-233 | 1 | 2ND REDUCTION PINION SNAP RING FOR: 6, 9, 10, 15.2, 18, 30, 26, 39, AND 6'18 FPM UNITS ONLY. | 45766 |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|--|-------------|
| 652-234 | 1 | TROLLEY CONTACTOR BRACKET | 52722 |
| 652-235 | 1 | TROLLEY SPEED SELECTOR INSULATOR | 52723 |
| 652-236 | 1 | TROLLEY SPEED SELECTOR WITH: 115 VOLT COIL | 28806 |
| | | 48 VOLT | 28848 |
| | | 24 VOLT COIL | 28829 |
| 652-237 | 2 | TRO. CONTACTOR BRACKET SCREW | 25862 |
| 652-238 | 2 | TRO. SPEED SELECTOR SCREW | 25859 |
| 652-239 | 2 | TROLLEY CONTACTOR SCREW | 25866 |
| 652-240 | 1 | TERMINAL INSULATOR | 35881 |
| 652-241 | -- | TROLLEY CONTACTOR JUMPERS: 3-51661 JUMPER AND 1-51699 JUMPER | -- |
| 652-242 | 3 | TROLLEY CONTACTOR TO SPEED SELECTOR JUMPER | 51661 |
| 652-243 | 1 | HOIST CONTACTOR TO TROLLEY CONTACTOR HARNESS | 51118 |
| 652-244 | 4 | BRAKE ATTACHING SCREW | 946801 |
| 652-245 | 2 | LODESTAR XL LABEL | 52760 |
| 652-246 | 1 | CONTROL CORD ATTACHING SCREW | 982688 |
| 652-247 | 1 | CONTROL CORD ATTACH. SCREW L. W. | 982226 |
| 652-248 | 1 | CONTROL CORD ATTACH. SCREW WASHER | 927835 |
| 652-249 | 1 | WARNING TAG | 81704 |
| 652-250 | 1 | CONTROL CORD ASSEMBLY FOR: SINGLE SPEED HOIST WITH 10 FT. LIFT | 28450 |
| | | TWO SPEED HOIST WITH 10 FT. LIFT | 36584 |
| | | SINGLE OR TWO SPEED HOIST WITH 10 FT. LIFT AND MOTOR DRIVEN TROLLEY (FOR OTHER LIFTS CONTACT CM) | 51711 |
| 652-251 | 2 | END COVER GASKET (WEATHER PROOF UNITS ONLY) | 52759 |
| 652-252 | 2 | CONTACTOR MOUNTING SCREW | 982686 |
| 652-253 | 1 | DEAD END BLOCK SPACER | 52064 |
| 652-254 | 1 | CONV. T.B. LABEL-LONG | 52721 |
| 652-255 | 1 | TROLLEY CORD HOLE PLUG | 989052 |
| 652-256 | 1 | LOOSE END SCREW | 982667 |
| 652-257 | 1 | LOOSE END SCREW WASHER | 987898 |
| 652-258 | 1 | LOOSE END SCREW WASHER | 45915 |
| 652-259 | 1 | CONV. T.B. LABEL-SHORT | 52762 |
| 652-261 | 1 | CONTROL GROMMET | 27891 |
| 652-262 | 1 | ROTOR BEARING -OUTBOARD | 83692 |
| 652-263 | 1 | ROTOR BEARING -INBOARD | 83689 |

Notes:

- Includes 652-128
- Includes 652-122, 652-123, 652-125, 652-134, and 652-141.
- Includes 652-122, 652-123, 652-124, 652-126, 652-132, 652-141, and 652-187.
- Includes Dowel Pins, 652-129, 652-143, and 652-144.
- Dual Voltage (208-240/440-480, 220/380 and 220/415) units use 230 volt brake coil part number 68877.
- If complete Latchlok Type Hook Suspension is Required, Contact Factory.

| Part number for Packaged Lubricants Used in the XL Electric Chain Hoists (Refer to page 15 for Lubrication Instructions) | | |
|---|--------------------------------|--|
| Lubricant Usage | Type of Lubricant | Part Numbers and Packaged Quantity of Lubricants |
| Hoist Gears | Grease Oils (Amoco 85W-140) | 52776 for 1 Gal. Can |
| Splines | *Grease | EP Type Grease - Obtain Locally |
| Load Chain | Oil | 28608 for 1 Pint Can 28619 for 1 Gal. Can |
| Limit Switch Shaft Threads | *Oil | "3 in 1" or Light Machining Oil - Obtain Locally |
| Lower Hook Thrust Bearing | *Oil | Heavy Machining Oil Obtain Locally |
| Trolley Trackwheel Bearings and Gears | Grease (Novatex #2) | 28632 for 4 lb. Can 28610 for 1 lb. Can |
| Trolley Gears | Grease (Novatex #1) | 28613 for 4 lb. Can 28612 for 1 lb. Can |

*These lubricants are not furnished by in Packaged Quantities.

When ordering lubricants, specify the type of lubricant, part number and packaged quantity required.


Touch-up Paints for Lodestar XL Electric Chain Hoists and 2 Ton Trolley Order: (1) case (12-12 oz. Aerosol Cans) of Orange Touch-up paint Part Number 84190.

Touch-up Paints for 3-7½ Ton Trolleys order: (1) case (12-12 oz. Aerosol Cans) of Black Touch-up Paint Part Number 84189.

Touch-up paint is only available in case quantities.

Note: When painting Hoists or Trolley, also order warning labels, identification labels, etc. that may be coating during painting.


3 THRU 7½ TON MOTOR AND GEAR BOX ASSEMBLY



*SEE PAGE 47 FOR TROLLEY BRAKE ASSEMBLY

| REF. NO. | NO. REQ'D | PART DESCRIPTION | PART NUMBER |
|----------|--------------|---|-------------|
| | | | 3-7 1/2 TON |
| | 1 | MOTOR & GEARBOX ASS'Y (LESS POWER CORD) | BET-3000 |
| 1 | 1 | MOTOR (INCLUDES REF. NO.2 | BET-3001 |
| 2 | 1 | MOTOR KEY (3/16 X 3/16 X 1 1/4") | BET-3002 |
| | 1 | GEAR BOX ASS'Y - COMPLETE | BET-3003 |
| 3 | 1 | ELECTRICAL WARNING LABEL | 24842 |
| 4 | 1 | POWER CONNECTOR LOCKNUT | 989771 |
| 5 | 4 | LOCKWASHER | BET-3006 |
| 6 | 4 | HEX HEAD BOLT (3/8-16 X 7/8) | BET-3007 |
| 7 | 1 | POWER CORD | 51120 |
| 8 | SPECIFY QTY. | WIRE NUT | 983812 |
| 9 | 1 | POWER CORD CONNECTOR | 89926 |
| 10 | 1 | WEATHERPROOF O-RING | 983967 |
| 11 | SPECIFY QTY. | LINE CONNECTOR | 982158 |

*SEE ALSO 652-219 COUNTER WEIGHT IF ORDERING HOOK SUSPENSION PARTS SEPARATELY.




Lodestar XL Electric Chain Hoist Exploded View

•For control station and control station parts see pages 45 and 46

Double and Triple Reeved

Single Reeved




2 TON Plain, Geared and Motor Driven Trolleys Parts List.

| Key No. | No. Req'd | Part Name | Part Number |
|--------------------------------------|-----------|--|-------------|
| | | | 2 TON |
| 652-186 | 2 | WARNING LABEL, ELECTRICAL | 24842 |
| 652-300 | 1 | TROLLEY POWER CORD | 51117 |
| 652-301 | 1 | HOIST SUSPENSION ADAPTER | 52059 |
| 652-302 | 1 | SUSPENSION ADAPTER SCREW / DEAD END BOLT | 987208 |
| 652-303 | 1 | "CM" LABEL | 25779 |
| 670-304 | 2 | SUSPENSION BOLT FOR : | |
| | | 3.25" TO 5.50" FLANGE (82.6 to 139.7 mm) | 58503 |
| | | 5.51" TO 7.63" FLANGE (139.9 to 193.8 mm) | 59350 |
| 670-305 | 4 | SUSPENSION BOLT NUT | 958818 |
| 670-306 | 4 | SUSPENSION BOLT NUT COTTER PIN | 988368 |
| 670-307 | — | SPACER WASHER - SPECIFY NO. REQ'D. | 958726 |
| 670-308 | 4 | TRACKWHEEL WITH BEARING CUP : CROWNED TREAD | 58162 |
| 670-309 | 8 | TRACKWHEEL BEARING CUP | 88521 |
| 670-310 | 8 | TRACKWHEEL BEARING CONE | 88525 |
| 670-311 | 8 | TRACKWHEEL BEARING SHIELD | 68918 |
| 670-312 | 4 | TRACKWHEEL STUD | 58459 |
| 670-313 | 4 | TRACKWHEEL STUD COLLAR | 58484 |
| 670-314 | 4 | TRACKWHEEL STUD NUT | 982613 |
| 670-315 | 2 | TRACKWHEEL GEAR FOR : | |
| | | GEARED TROLLEY | 58548 |
| | | 35 AND 65 FPM TROLLEYS (10.7 and 19.8 MPM) | 58548 |
| | | 50 FPM TROLLEYS (15.2 MPM) | 58548 |
| | | 100 FPM TROLLEY (30.4 MPM) | 58548 |
| | | 35/65 FPM TROLLEYS (10.7/ 19.8 MPM) | 58548 |
| | | 25/50 FPM TROLLEYS (7.6/ 15.2 MPM) | 58548 |
| 50/100 FPM TROLLEY(15.2/ 30.4 MPM) | 58548 | | |
| 670-316 | 4 | TRACKWHEEL GEAR PIN | 983503 |
| 670-317 | 1 | TRACKWHEEL GEAR PINION FOR: | |
| | | GEARED TROLLEY | 58505 |
| | | 35 AND 65 FPM TROLLEYS (10.7 and 19.8 MPM) | 58505 |
| | | 50 FPM TROLLEYS (15.2 MPM) | 58505 |
| | | 100 FPM TROLLEY (30.4 MPM) | 58505 |
| | | 35/65 FPM TROLLEYS (10.7/ 19.8 MPM) | 58505 |
| | | 25/50 FPM TROLLEYS (7.6/ 15.2 MPM) | 58487 |
| 50/100 FPM TROLLEYS (15.2/ 30.4 MPM) | 58505 | | |
| 670-318 | 1 | TRACKWHEEL PINION KEY | 85546 |
| 670-319 | 1 | GEARED SIDE FRAME FOR : | |
| | | 3.25" TO 5.50" FLANGE (82.6 to 139.7 mm) | 59615 |
| | | 5.51" TO 7.63" FLANGE (139.9 to 193.8 mm) | 58618 |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------------------------------|---|-------------|
| | | | 2 TON |
| 670-320 | 2 REQ'D. FOR PLAIN TROLLEYS | PLAIN SIDE FRAME FOR: | |
| | | 3.25" TO 5.50" FLANGE (82.6 to 139.7 mm.) | 59614 |
| | | 5.51" TO 7.63" FLANGE (139.9 to 193.8 mm.) | 58617 |
| | | 1 REQ'D. FOR GEARED AND MOTOR DRIVEN TROLLEYS | 52152 |
| | | 3.25" TO 5.50" FLANGE (82.6 to 139.7 mm.) FOR USE WITH ANTI-TIPPING ROLLER | |
| 670-321 | 1 | HANDWHEEL BRACKET WITH BUSHINGS | 59616 |
| 670-322 | 2 | HANDWHEEL BUSHING | 58727 |
| 670-323 | 3 | HANDWHEEL BRACKET SCREW L.W. | 945853 |
| 670-324 | 3 | HANDWHEEL BRACKET SCREW | 987061 |
| 670-325 | 1 | HANDWHEEL SHAFT | 58504 |
| 670-326 | 1 | HANDWHEEL KEY | 59967 |
| 670-327 | 1 | HANDWHEEL | 33143 |
| 670-328 | 1 OR 2 | TRACKWHEEL PINION OR HANDWHEEL SHAFT NUT L.W. | 986270 |
| 670-329 | 1 OR 2 | TRACKWHEEL PINION OR HANDWHEEL SHAFT NUT | 988095 |
| 670-330 | 1 | HANDCHAIN GUIDE | 58152 |
| 670-331 | 1 | CHAIN GUIDE SCREW | 987065 |
| 670-332 | 1 | CHAIN GUIDE SCREW WASHER | 986224 |
| 670-333 | 1 | CHAIN GUIDE SCREW L.W. | 945853 |
| 670-334 | 1 | CHAIN GUIDE SCREW NUT | 945822 |
| 670-335 | — | HAND CHAIN - SPECIFY LENGTH REQ'D. | 619022 |
| 670-336 | 1 | HAND CHAIN CONNECTING LINK | 945491 |
| 670-337 | — | TRACKWHEEL PINION SPACER WASHER-SPECIFY NO. REQ'D. | 987963 |
| 670-338 | 1 | TRACKWHEEL PINION SHAFT | 58450 |
| 670-339 | 1 or 2 | TRACKWHEEL PINION SPACER -- SPECIFY NO. REQ'D. | 58456 |
| 670-341 | 2 | PINION SHAFT BEARING | 88438 |
| 670-342 | 1 | INTERMEDIATE SHAFT BEARING -- SIDE FRAME END | 88437 |
| 670-343 | 1 | INTERMEDIATE SHAFT BEARING --MOTOR END | 88436 |
| 670-344 | 1 | DRIVEN GEAR | 58451 |
| 670-345 | 1 | INTERMEDIATE PINION | 58452 |
| 670-346 | 1 | INTERMEDIATE GEAR FOR : | |
| | | 35 AND 65 FPM TROLLEYS (10.7 and 19.8 MPM) | 58453 |
| | | 50 FPM TROLLEYS (15.2 MPM) | 58407 |
| | | 100 FPM TROLLEY (30.4 MPM) | 58407 |
| | | 35/65 FPM TROLLEYS (10.7/ 19.8 MPM) | 58453 |
| | | 25/50 FPM TROLLEYS (7.6/ 15.2 MPM) | 58453 |
| Con't. | | 50/100 FPM TROLLEY (15.2/ 30.4 MPM) | 58453 |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|---|-------------|
| | | | 2 TON |
| 670-347 | 1 | MOTOR PINION FOR : | |
| | | 35 AND 65 FPM TROLLEYS (10.7 and 19.8 MPM) | 54356 |
| | | 50 FPM TROLLEYS (15.2 MPM) | 58406 |
| | | 100 FPM TROLLEYS (30.4 MPM) | 58406 |
| | | 35/65 FPM TROLLEYS (10.7/ 19.8 MPM) | 54356 |
| | | 25/50 FPM TROLLEYS (7.6/ 15.2 MPM) | 54356 |
| 670-348 | 1 | MOTOR PINION PIN | 988263 |
| 670-349 | 1 | DRIVEN GEAR KEY | 989096 |
| 670-350 | 2 | PINION BEARING SPACER | 58456 |
| 670-351 | 1 | INTERMEDIATE BEARING SPACER | 58728 |
| 670-352 | 1 | INTERMEDIATE PINION NUT | 988146 |
| 670-353 | 1 | INTERMEDIATE PINION NUT L.W. | 986266 |
| 670-354 | 1 | GEAR HOUSING | 70064 |
| 670-355 | 1 | GEAR HOUSING GASKET | 58729 |
| 670-356 | 4 | GEAR HOUSING SCREW | 987019 |
| 670-357 | 4 | GEAR HOUSING SCREW L.W. | 945851 |
| 670-358 | 1 | MOTOR END BELL GASKET - | 58730 |
| 670-359 | 1 | BRAKE HUB | 59363 |
| 670-360 | 1 | BRAKE HUB SNAP RING | 27766 |
| 670-361 | 2 | BRAKE ATTACHING SCREW | 982708 |
| 670-362 | 2 | BRAKE ATTACHING SCREW L.W. | 982226 |
| 670-363 | 2 | MOTOR COVER GASKET - WEATHERPROOF UNITS ONLY | 68756 |
| 670-364 | 1 | BRAKE COVER | 58161 |
| 670-365 | 3 | BRAKE COVER SCREW | 968752 |
| 670-366 | 3 | BRAKE COVER SCREW L.W. FOR : | |
| | | NON-WEATHERPROOF UNITS | 940802 |
| | | WEATHERPROOF UNITS | 982251 |
| 670-367 | 1 | MOTOR END COVER | 68751 |
| 670-368 | 3 | MOTOR END COVER SCREW | 982717 |
| 670-369 | 3 | MOTOR END COVER SCREW L.W. FOR : | |
| | | NON-WEATHER PROOF UNITS | 982226 |
| | | WEATHERPROOF UNITS | 982251 |
| 670-370 | 1 | TERMINAL BOX AND COVER | 58120 |
| 670-372 | 1 | TERMINAL BOARD | 68837 |
| 670-373 | 1 | TERMINAL BOX SCREW | 927930 |
| 670-374 | 1 | TERMINAL BOX SCREW L.W. | 982226 |
| 670-375 | 2 | TERMINAL BOARD SPACER | 68776 |
| 670-376 | 2 | TERMINAL BOX AND BOARD SCREW | 982695 |
| 670-377 | 2 | TERMINAL BOX AND BOARD SCREW L.W. | 986290 |

| KEY NO. | NO. REQ'D | PART NAME | PART NUMBER |
|---------|-----------|---|-------------|
| | | | 2 TON |
| 670-378 | 1 | POWER CORD CONNECTOR | 89926 |
| 670-380 | 1 | TERMINAL BOX GASKET | 59991 |
| 670-407 | 1 | TROLLEY MOTOR (REFER TO MOTOR NAMEPLATE) : | |
| | | .5 HP, 600 RPM, 230/460 V. | 57766 |
| | | .5 HP, 600 RPM, 575 V. | 57782 |
| | | .5 HP, 1200 RPM, 230/460 V. | 68916 |
| | | .5 HP, 1200 RPM, 575 V. | 57771 |
| | | .25/.5 HP, 600/1200 RPM, 230 V. | 57273 |
| | | .25/.5 HP, 600/1200 RPM, 460 V. | 57274 |
| | | .25/.5 HP, 900/1800 RPM, 230 V. | 57778 |
| 670-420 | 1 | TROLLEY BRAKE (INCLUDES 670-421, 670-422, 670-423, AND 670-425 THROUGH 670-431) FOR : | |
| | | 230/460 V. SINGLE SPEED AND 230 V. TWO SPEED TROLLEYS | 59692 |
| | | 460 V. TWO SPEED TROLLEYS | 59694 |
| | | 575 V. SINGLE AND TWO SPEED TROLLEYS | 59693 |
| | | 670-421 | 1 |
| 670-422 | 1 | FRICITION DISC | 27677 |
| 670-423 | 1 | BRAKE ARMATURE | 28678 |
| 670-425 | 1 | BRAKE COIL FOR: | |
| | | 230/460V. SINGLE SPEED AND 230 V. TWO SPEED TROLLEYS | 51518 |
| | | 460 V. TWO SPEED TROLLEYS | 51519 |
| | | 575 V. SINGLE AND TWO SPEED TROLLEYS | 51520 |
| 670-426 | 1 | BRAKE COIL RETAINER STRAP | 57753 |
| 670-427 | 1 | BRAKE FIELD | 28677 |
| 670-428 | 2 | BRAKE SPRING | 68750 |
| 670-429 | 10 | BRAKE SPACER WASHER | 954807 |
| 670-430 | 2 | BRAKE STUD NUT | 945840 |
| 670-431 | 2 | SHADING COIL | 54831 |
| 670-462 | 1 | WARNING LABEL | 936984 |
| 670-463 | 1 | CAPACITY LABEL | 957928 |
| 670-464 | 1 | ANTI-TIPPING ROLLER KIT | 52813 |




**3 THRU 7½ TON
PLAIN, GEARED AND MOTOR DRIVEN
TROLLEYS
EXPLODED VIEW**

| REF. NO. | NO. REQ'D | PART DESCRIPTION | PART NUMBER | | | | | |
|----------|-----------|--------------------------------------|-------------|-----------|--------------|-------------|-----------|--------------|
| | | | 3 TON | | | 4-7 1/2 TON | | |
| | | | PLAIN | GEARED | MOTOR DRIVEN | PLAIN | GEARED | MOTOR DRIVEN |
| 1 | 2 | SIDE PLATE ASSEMBLY FOR: | | | | | | |
| | | 4" TO 6 1/4" FLG. AND PATENTED TRACK | 700T-1400 | 700T-1700 | BET-2800 | 700T-1501 | 700T-1801 | BET-3801 |
| | | 6 3/8" TO 8 5/8" FLG. | 700T-1402 | 700T-1701 | BET-2801 | 700T-1504 | 700T-1803 | BET-3803 |
| | | 8 3/4" TO 11" FLG. | 700T-1404 | 700T-1702 | BET-2802 | 700T-1507 | 700T-1805 | BET-3805 |
| 2 | 8 | BALL BEARING | 700T-1406 | 700T-1703 | BET-2803 | 700T-1514 | 700T-1811 | BET-3811 |
| 3 | 4 | RETAINING RING | 700T-1407 | 700T-1704 | BET-2804 | 700T-1516 | 700T-1813 | BET-3813 |
| 4 | 2 | *TRACKWHEEL-PLAIN | | | | | | |
| | | STANDARD | 700T-1408 | 700T-1705 | BET-2805 | 700T-1518 | 700T-1815 | BET-3815 |
| | | PATENTED TRACK | 700T-1409 | 700T-1706 | BET-2806 | 700T-1520 | -- | BET-3817 |
| | | SPARK RESISTANT | 700T-1410 | 700T-1707 | -- | 700T-1521 | 700T-1818 | -- |
| 5 | 2 | TRACKWHEEL-GEARED | | | | | | |
| | | STANDARD | -- | 700T-1708 | BET-2807 | -- | 700T-1820 | BET-3818 |
| | | PATENTED TRACK | -- | 700T-1709 | BET-2808 | -- | -- | BET-3820 |
| | | SPARK RESISTANT | -- | 700T-1710 | -- | 700T-1823 | -- | |
| 6 | 4 | RETAINING RING | 700T-1411 | 700T-1711 | BET-2809 | 700T-1523 | 700T-1825 | BET-3821 |
| 7 | 1 | PINION | -- | 700T-1719 | BET-2810 | -- | 700T-1846 | BET-3823 |
| 8 | 1 | PINION KEY | -- | 700T-1720 | BET-2811 | -- | 700T-1847 | BET-3824 |
| 9 | 2 | **RETAINING RING | -- | 700T-1718 | BET-2812 | -- | 700T-1845 | BET-3825 |
| 10 | 4 | HEX CAP SCREW | -- | 700T-1721 | BET-2813 | -- | 700T-1848 | BET-3826 |
| 11 | 4 | SELF LOCKING NUT | -- | 700T-1725 | BET-2814 | -- | 700T-1853 | BET-3828 |
| 12 | 4 | HEX JAM NUT | 700T-1412 | 700T-1712 | BET-2815 | 700T-1526 | 700T-1828 | BET-3830 |
| 13 | 4 | LOCKWASHER | 700T-1414 | 700T-1713 | BET-2816 | 700T-1529 | 700T-1831 | BET-3833 |
| 14 | 40 | SPACER WASHERS | 700T-1416 | 700T-1714 | BET-2817 | 700T-1532 | 700T-1834 | BET-3836 |
| 15 | 2 | SUSPENSION PIN FOR: | | | | | | |
| | | 4" TO 6 1/4" FLG. AND PATENTED TRACK | 700T-1418 | 700T-1715 | BET-2818 | 700T-1535 | 700T-1837 | BET-3839 |
| | | 6 3/8" TO 8 5/8" FLG. | 700T-1420 | 700T-1716 | BET-2819 | 700T-1537 | 700T-1839 | BET-3841 |
| | | 8 3/4" TO 11" FLG. | 700T-1422 | 700T-1717 | BET-2820 | 700T-1539 | 700T-1841 | BET-3843 |
| 16 | 2 | BUSHING | -- | 700T-1723 | -- | -- | 700T-1851 | -- |
| 17 | 1 | PLATE AND TUBE ASSEMBLY | -- | 700T-1724 | -- | -- | 700T-1852 | -- |
| 18 | 2 | RETAINING RING | -- | 700T-1722 | -- | -- | 700T-1850 | -- |
| 19 | 1 | HANDWHEEL SHAFT | -- | 700T-1726 | -- | -- | 700T-1854 | -- |
| 20 | 1 | HANDWHEEL SHAFT KEY | -- | 700T-1727 | -- | -- | 700T-1856 | -- |
| 21 | 2 | WASHER | -- | 700T-1728 | -- | -- | 700T-1857 | -- |
| 22 | 2 | CHAIN GUIDE | | | | | | |
| | | 8 5/8" O.D. HAND CHAIN WHEEL | -- | 700T-1729 | -- | -- | -- | -- |
| | | 11 5/8" O.D. HAND CHAIN WHEEL | -- | 700T-1730 | -- | -- | 700T-1858 | -- |
| 23 | 1 | HAND CHAIN WHEEL | | | | | | |
| | | 8 5/8" OUTSIDE DIAMETER | -- | 700T-1731 | -- | -- | -- | -- |
| | | 11 5/8" OUTSIDE DIAMETER | -- | 700T-1732 | -- | -- | 700T-1860 | -- |
| 24 | 1 | SUSPENSION ADAPTER | | 52784 | | | 52787 | |
| 25 | 1 | SUSPENSION ADAPTER SCREW | | 80430 | | | 80430 | |
| 26 | 1 | WARNING LABEL | -- | 936986 | -- | -- | 936986 | -- |
| 27 | 1 | TROLLEY CAPACITY LABEL | | 52764 | | | 52765 | |
| 28 | 1 | WARNING LABEL | | 936984 | | | 936984 | |
| 29 | 1 | ANTI-TIPPING ROLLER KIT | | 44927630 | | | 44927660 | |
| *** | AS REQ'D | HAND CHAIN (NOT SHOWN) | | | | | | |
| | | STANDARD | -- | 700T-1733 | -- | -- | 700T-1862 | -- |
| | | SPARK RESISTANT | -- | 700T-1734 | -- | -- | 700T-1863 | -- |


* TOTAL QUANTITY OF 4 EACH REQUIRED FOR PLAIN TYPE TROLLEYS.

** TOTAL QUANTITY OF 1 EACH REQUIRED FOR 3 TON TROLLEYS.

*** SPECIFY LENGTH OF HAND CHAIN REQUIRED. STANDARD LENGTH EQUALS TWO TIMES HOIST LIFT PLUS 2'-6".




| Single Speed Hoist Control Station | | | |
|------------------------------------|--|------|-------------|
| Key No. | Part Name | Qty. | Code |
| 627-250 | Standard Control Cord Assembly | 1 | See page 35 |
| 627-551 | Control Station Grommet | 1 | 58278 |
| 627-552 | Control Station (Includes 627-551 thru 627-567) | 1 | 58272 |
| 627-563 | Control Station Hardware Kit w/gasket | 1 | 58275 |
| 627-565 | Control Station 1-speed Insert | 1 | 58255 |
| 627-566 | Control Station Warning Label Kit (Includes Exterior Labels) | 1 | 57276 |
| 627-567 | Contol Station Button Label Kit | 1 | 58277 |




| Two Speed Hoist Control Station | | | |
|---------------------------------|--|------|-------------|
| Key No. | Part Name | Qty. | Code |
| 627-250 | Standard Control Cord Assembly | 1 | See Page 35 |
| 627-551 | Control Station Grommet | 1 | 58278 |
| 627-552 | Control Station (Included 627-551 Thru 627-567) | 1 | 58273 |
| 627-563 | Control Station Hardware Kit w/gasket | 1 | 58275 |
| 627-565 | Control Station 2-speed Insert | 1 | 58256 |
| 627-566 | Control Station Warning Label Kit (Includes Exterior Labels) | 1 | 57276 |
| 627-567 | Contol Station Button Label Kit | 1 | 58277 |

4 DIRECTIONAL CONTROL STATION PARTS LIST



| 4 Directional Control Station | | | |
|-------------------------------|--|------|-------------|
| Key No. | Part Name | Qty. | Code |
| 627-451 | Standard Control Cord Assembly | 1 | See Page 35 |
| 627-551 | Control Station Grommet | 1 | 58278 |
| 635-156 | Control Station (Includes 627-551 Thru 627-567) | 1 | 58220 CM |
| 627-553 | Control Station Housing Kit (Includes Housing, Boots, Collar, Gasket & Hardware) | 1 | 58288 |
| 627-563 | Control Station Hardware Kit w/gasket | 1 | 58279 |
| 627-565 | Control Station 1-Speed Insert | 1 | 58522 |
| | Control Station 2-Speed Insert | 1 | 58256 |
| 627-566 | Control Station Warning Label Kit | 1 | 57276 |
| 627-567 | Contol Station Button Label Kit | 1 | 58277 |

3 THRU 7½ TON TROLLEY MOTOR BRAKE EXPLODED VIEW



| Key No. | No. Req'd | Part Name | Part Number | |
|---------|-----------|---|---|--|
| 1 | 1 | Brake Cord | 51074 | |
| 2 | 1 | Coupler Brake Shaft Kit (includes Shaft, Bearing, Snap Ring, Retainer Ring and Key) | Contact Factory For Part Numbers Of Brake Components Key Numbers 2 Thru 28, 32 And 33 | |
| 3 | 1 | Housing | | |
| 4 | 4 | Mounting Stud with Nut | | |
| 5 | 2 | Access Cover -Plain | | |
| 6 | - | Access Cover Screw (Specify No. Req'd.) | | |
| 7 | 2 | *Access Cover Gasket | | |
| 8 | 1 | *Drain Plug | | |
| 9 | 1 | *Housing To End Plate Gasket | | |
| 10 | 2 | *Gasket-Each End Of Brake | | |
| 11 | 1 | Stationary Disc | | |
| 12 | 1 | Friction Disc Kit (Includes 3 Discs With Stabilizer Spring-Only One Disc Req'd.Per Brake) | | |
| 13 | 1 | Hub Kit (Included Hub And Set Screws) | | |
| 14 | 1 | End Plate Assembly | | |
| 15 | 1 | Plug-External Lead Hole | | |
| 16 | 1 | Bearing | | |
| 17 | 1 | Solenoid Lever | | |
| 18 | 1 | Retaining Ring | | |
| 19 | 2 | Spacer | | |
| 20 | 2 | Torque Adjusting Screw | | |
| 21 | 2 | Wear Adjusting Screw | | |
| 22 | 2 | Pressure Spring | | |
| 23 | 1 | Lever Arm And Stop Nut Assembly | | |
| 24 | 1 | Bearing Pin | | |
| 25 | 1 | Support Plate And Stop Nut Assembly | | |
| 26 | 1 | Pivot Pin | | |
| 27 | 1 | Solenoid Kit (Includes Plunger, Link, Frame Link Screw, Link Nut And Mounting Screws) | | |
| 28 | 1 | Coil Kit (Includes Coil, Plunger Guides, Guide Screw and Locwashers) | | |
| 29 | 1 | Motor Brake Kit (Includes Complete Brake Assembly, Brake Cord, Connector Wire Nuts and Installation Instructions) | | 9598 for 220, 230 380 & 460 Volt Brake 83968 |
| 30 | 1 | Brake Cord Connector | | 83968 |
| 31 | 4 | Wire Nut | 982473 | |
| 32 | 3 | Brake Attaching Screw | Contact Factory | |
| 33 | 1 | **Access Cover With Manual Release Knob | Contact Factory | |

* For Weatherproof Units-Not Shown

**Not Shown

NOTES

Note: When ordering parts, always furnish Hoist Model and Serial Number, Motor Horsepower, Voltage, Phase, Frequency and Rated Capacity of hoist on which the parts are to be used.

For the location of the nearest Master Parts Depot, see the list located on the inside front cover.

LIMITATION OF WARRANTIES, REMEDIES AND DAMAGES

THE WARRANTY STATED BELOW IS GIVEN IN PLACE OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHERWISE, NO PROMISE OR AFFIRMATION OF FACT MADE BY ANY AGENT OR REPRESENTATIVE OF SELLER SHALL CONSTITUTE A WARRANTY BY SELLER OR GIVE RISE TO ANY LIABILITY OR OBLIGATION.

Seller warrants that on the date of delivery to carrier the goods are free from defects in workmanship and materials.

SELLER'S SOLE OBLIGATION IN THE EVENT OF BREACH OF WARRANTY OR CONTRACT OR FOR NEGLIGENCE OR OTHERWISE WITH RESPECT TO GOODS SOLD SHALL BE EXCLUSIVELY LIMITED TO REPAIR OR REPLACEMENT, F.O.B. SELLER'S POINT OF SHIPMENT, OF ANY PARTS WHICH SELLER DETERMINES TO HAVE BEEN DEFECTIVE or if Seller determines that such repair or replacement is not feasible, to a refund of the purchase price upon return of the goods to Seller.

Any action against Seller for breach of warranty, negligence or otherwise, must be commenced within one year after such cause of action accrues.

NO CLAIM AGAINST SELLER FOR ANY DEFECT IN THE GOODS SHALL BE VALID OR ENFORCEABLE UNLESS BUYER'S WRITTEN NOTICE THEREOF IS RECEIVED BY SELLER WITHIN ONE YEAR FROM THE DATE OF SHIPMENT.

Seller shall not be liable for any damage, injury or loss arising out of the use of the goods if, prior to such damage, injury or loss, such goods are (1) damaged or misused following Seller's delivery to carrier; (2) not maintained, inspected, or used in compliance with applicable law and Seller's written instructions and recommendations; or (3) installed, repaired, altered

or modified without compliance with such law, instructions or recommendations.

UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES AS THOSE TERMS ARE DEFINED IN SECTION 2-715 OF THE UNIFORM COMMERCIAL CODE.

INDEMNIFICATION AND SAFE OPERATION

Buyer shall comply with and require its employees to comply with directions set forth in instructions and manuals furnished by Seller and shall use and require its employees to follow such instructions and manuals and to use reasonable care in the use and maintenance of the goods. Buyer shall not remove or permit anyone to remove any warning or instruction signs on the goods. In the event of personal injury or damage to property or business arising from the use of the goods, Buyer shall within 48 hours thereafter give Seller written notice of such injury or damage. Buyer shall cooperate with Seller in investigating any such injury or damage and in the defense of any claims arising therefrom.

If Buyer fails to comply with this section or if any injury or damage is caused, in whole or in part, by Buyer's failure to comply with applicable federal or state safety requirements, Buyer shall indemnify and hold Seller harmless against any claims, loss or expense for injury or damage arising from the use of the goods.

WARNING

Alterations or modifications of equipment and use of non-factory repair parts can lead to dangerous operation and injury.

TO AVOID INJURY:

- Do not alter or modify equipment
- Do use only factory provided replacement parts.



Columbus McKinnon Corporation
140 John James Audubon Parkway
Amherst, New York 14228-1197
Phone: (800) 888-0985
Fax: (716) 689-5644